HDTV Satellite Receiver

ZAPPIX HD+

User Manual

Version: 14.05.2013 - English

ENJOY YOUR ENTERTAINMENT

Preface

Dear customer!

Thank you for purchasing a smart HDTV satellite receiver. This manual explains how to

- install,
- connect,
- customize,
- operate,
- clean or depollute

the receiver. Please read the manual carefully before operating the unit. We hope you enjoy using your smart receiver.

Your

smart electronic GmbH

Industriestrasse 29
78112 St. Georgen
Germany

Service-Hotline: +49 (0) 7724 947 85 55
Telefax: +49 (0) 7724 947 83 33
E-Mail: service@smart-electronic.de
Internet: www.smart-electronic.de

© smart electronic GmbH 2013

All rights, technical changes, errors as well as printing mistakes reserved. Any reproducing or copying of the contents requires prior written permission from smart.

Contents

1 General Advice 9
1.1 Use of this Manual 9
1.2 Symbols and Illustration Agreements 9
2 Product Description 10
2.1 Scope of Delivery 10
2.2 Receiver 11
2.2.1 Receiver Front 11
2.2.2 Rear Panel 12
2.3 Remote Control Unit 13
2.4 Save Energy 15
2.5 Warranty 15
3 Safety Instructions 15
3.1 Designated Use 15
3.2 Hazards during designated use 16
3.3 Grounding 16
3.4 Location 16
3.5 Proper Handling of Batteries 17
3.6 Product Liability 17
4 Connecting the Zappix HD+ 18
4.1 Connection Diagram 18
4.2 Connecting the Satellite System 18
4.3 Connecting the TV Set 19
4.4 Connecting a Home Theater System (optional) 19
4.5 Connecting a Data Storage Device (optional) 20
4.6 Connecting a Home Network (optional) 21
4.7 Connecting the Power Supply 21
4.8 Inserting the Batteries of the RCU 21
5 Basic Operation 21
5.1 Switching on the Receiver 21

5.2 Installation with RAPS ... 22
5.3 Installation without RAPS ... 25
5.3.1 Predefined List ... 25
5.3.2 Automatic (HD+) ... 26
5.4 Software Update ... 27
5.4.1 Update via USB ... 27
5.4.2 Online Update ... 27
5.4.3 OTA Update ... 28
5.4.4 Automatic Update ... 28
5.4.4.1 Update During Operation ... 29
5.4.4.2 Update During Standby-Mode ... 29
5.5 Operation Mode ... 29
5.6 Open/Close Menu ... 30
5.7 Menu Navigation ... 31
5.8 Watching TV ... 32
5.8.1 Channel Selection ... 32
5.8.2 Select Channel List ... 33
5.8.3 Recall ... 33
5.8.4 Teletext (Videotext) ... 33
5.8.5 Quick Access Menus ... 34
5.8.6 Adding a channel to a favorite ... 37
5.8.7 Subtitles ... 37
5.8.8 Aspect Ratio ... 37
5.8.9 TV Resolution ... 39
5.8.10 Soundtrack ... 40
5.8.11 Audio ... 40
5.8.12 Sleep Timer ... 41
5.8.13 Parental Control ... 42
5.8.14 Mini Guide ... 42
5.8.15 Full Guide ... 44
5.8.16 Personal Planner ... 46
5.8.17 List Manager ... 46
5.9 HbbTV ... 46

6 PVR 47
6.1 Record 47
6.2 Programming via EPG 48
6.3 Time Shifting 49
6.4 Playback 50
6.4.1 Direct Playback 50
6.4.2 Playback via the Media Player 50
6.5 Recording one Channel and Watching another at the same Time 50
6.6 Recording and Playing EPG Data 51
7 Extended Functions and Settings 51
7.1 TV/Radio 51
7.1.1 Live TV 51
7.1.2 Live Radio 51
7.1.3 Recorded TV 52
7.1.4 Define default directories 53
7.1.5 Formatting a storage device 54
7.1.6 Mounting/Unmounting an USB device 55
7.1.7 Testing a Storage Device 55
7.1.8 Personal Planner 55
7.1.9 List Manager 58
7.1.9.1 Delete a Channel List 58
7.1.9.2 New Channel List 59
7.1.9.3 Rename Channel List 59
7.1.9.4 Editing Channel Lists 59
7.1.9.5 Adding a Channel to a Favorite List 60
7.1.9.6 Deleting a Channel from a Favorite List 60
7.1.9.7 Sorting a Channel List 61
7.1.9.8 Moving a Channel in a Channel List 61
7.1.9.9 More List Editor Functions 61
7.2 Guide 62
7.3 Media Player 62
7.3.1 Network streaming 64

7.3.1.1 Password 64
7.3.1.2 Firewall 64
7.3.2 Receiver Settings for Streaming 64
7.3.3 How to Share Folders and Drives 65
7.3.3.1 How to Share Folders and Drives with Windows XP 65
7.3.3.2 How to Share Folders and Drives with Windows 7 66
7.3.4 Example Music 68
7.3.5 Example Photos 69
7.4 Web 69
7.5 Control Panel 70
7.5.1 User Preferences 71
7.5.1.1 Default State of the Receiver After Power-Up 71
7.5.1.2 Number of Channels in the Channel Memory 71
7.5.1.3 Setting the Energy mode 71
7.5.1.4 User Interface 72
7.5.1.5 Quick View Window Behavior 72
7.5.1.6 Getting Informed About Existing HbbTV Content 72
7.5.1.7 Automatic Standby-Mode 73
7.5.1.8 Functions for the Keys FAV, EPG and HELP 73
7.5.1.9 Automatic Playback of a Multimedia File 74
7.5.1.10 Leaving the Menu “User preferences” 74
7.5.2 Time / Date 75
7.5.3 Languages 76
7.5.4 Recording 76
7.5.4.1 Setting Lead Time and Overrun Time 76
7.5.4.2 Setting Default Directories for Recordings and Timeshift 76
7.5.4.3 Channel Change During Recording 77
7.5.4.4 Recording Subtitles 77
7.5.4.5 Recording Audio Tracks 77
7.5.4.6 Recording Teletext 77
7.5.4.7 Power at the USB Port 77
7.5.4.8 Blocking the menu during recording 77
7.5.5 Parental Control / Pin Code 78

7.5.6 Network 78
7.5.6.1 Wireless Network – WLAN 78
7.5.6.2 Showing Network Connection Parameters 80
7.5.6.3 Activating a Network Quality Control 80
7.5.7 Channel Search 80
7.5.7.1 Satellite Search 80
7.5.7.2 Advanced Channel Search 80
7.5.8 Factory Settings 81
7.5.9 System Update 82
7.5.10 System information 82
7.5.11 Audio / Video 82
7.5.11.1 Digital Audio Out 82
7.5.11.2 HDMI Output 82
7.5.11.3 TV Scart 83
7.5.11.4 HDCP 83
7.5.11.5 Disable Analog Video Output 83
7.5.11.6 Adaptive Scan HDMI 83
7.5.12 Antenna 84
7.5.13 Smartcard 85
7.5.14 RAPS Config 85
7.6 Sorting Channels 86
7.7 EPG More options 87
7.8 Using USB Input Devices (Mouse, Keyboard) 88
7.8.1 The USB Mouse or the USB Keyboard is the only USB Device 90
7.8.2 Several USB Devices 91

8 Operation in a Unicable System 91

8.1 About Unicable 91
8.2 Allocation ZF Channels and Frequencies 91
8.3 Installation 92

9 Management of USB Storage Devices 93

9.1 USB Sticks 93
9.2 USB Hard Drive 2.5 "(Inch) 93

9.3 USB Hard Drive 3.5 "(Inch) ... 93
9.4 Check the Read and Write Speed ... 94
9.5 File System ... 94
9.6 Partitions on the Storage Device ... 94
9.7 Memory Requirements for Recording ... 94
9.8 Troubleshooting USB Storage Devices ... 95
9.9 Error Checking in Windows ... 96

10 Cleaning ... 96

11 Transport and Shutdown ... 96

12 Troubleshooting ... 97

13 Disposal ... 98

14 Specifications ... 99

14.1 General ... 99
14.2 Remote Control ... 100
14.3 LAN/WLAN ... 100
14.4 Power Supply ... 100
14.5 Connections ... 100
14.6 Temperature ... 100
14.7 Dimensions and Weight ... 101

15 Open-Source-Software ... 101

16 Declaration of Conformity ... 107

1 General Advice

1.1 Use of this Manual

- This manual is valid for the smart HDTV satellite receiver smart Zappix HD+.
- Read the manual completely before starting up the receiver the first time.
- Pay attention to all warnings and notes in the manual.
- Consider the manual as a part of the product and preserve it well accessible.
- If passing the set to third party, do not forget to attach this manual.
- In the support area of our website www.smart-electronic.de you can download the up-to-date version of the manual, e. g. if the original manual is lost.
- After purchasing the receiver the software will still be enhanced. Therefore, it may be possible that there are differences in e. g. operating instructions or illustrations between the manual and the reality.
- For many menu items there is detailed help shown as part of the OSD. In these cases there will not be any additional explanation in the manual.

1.2 Symbols and Illustration Agreements

Illustration	Meaning
	WARNING Hazard of electric shock with possibly serious bodily harm effect.
	CAUTION Warning of material damage.
☞	**Advice** Additional information and hints.
➢	You are asked to do something.
1. 2.	Act in the described order

Illustration	Meaning
●	enumeration
italic	various possibilities of an adjustable value are written in *italics*
bold	menu windows, menu items and key names are printed in **bold**

2 Product Description

2.1 Scope of Delivery

- HDTV satellite receiver smart Zappix HD+.
- remote control (rc)
- 2 batteries (AAA) for the rc
- HD+ smartcard (in the CA bay behind the front flap), HD+ info flyer
- user's manual

In the accessory shop on www.smart-electronic.de you can get the **smartPORTAL-Stick PX1** (USB WLAN stick).

Only with the smartPORTAL-Stick PX1 you can access all described network- and internet functions.

2.2 Receiver

2.2.1 Receiver Front



No.	Description	
1	**STANDBY**	Switch standby / operating mode
2	◀	Decrease volume / to the left in the menu
	▶	Increase volume / to the right in the menu
	OK	Show channel list / confirm menu item
	▼	Channel Down / down in the menu
	▲	Channel Up / up in the menu
3	**EXIT**	Exit menu or menu item
4	**MENU**	Display menu or exit menu
5	**Display**	4-digit display (channel)
6	**HD+**	Bay for smartcard

2.2.2 Rear Panel



No.	Description	
1	**LNB OUT**	SAT signal - loop through for additional receivers
2	**LNB IN**	Antenna connection
3	**Digital Audio**	Digital audio out (SPDIF)
4	**AUDIO-R**	Analog audio right
5	**SPDIF Optical**	Digital audio optical out
6	**USB**	USB data storage medium
7	**HDMI**[1]	Digital audio / video out
8	**TV**	Scart connection to a TV set
9	**Video**	Composite, analog TV video signal
10	**AUDIO L**	Analog audio left
11	**ON / OFF**	Mains switch

[1] High Definition Multimedia Interface, interface for the fully digital transmission of audio and video data.

2.3 Remote Control Unit

No.	Key	Description
1	⏻	Switches between operating mode and standby
2	**V-FORMAT**	Toggles video resolution
3	**0 - 9**	Program selection, alphanumeric input
4	**TV/R**	Switches between TV mode and Radio mode
5	**+/-**	Volume +/-
6	🟢	Green function key
7	🔴	Red function key

No.	Key	Description
8	**MENU**	Display main menu
9	▲	Program Up / up in the menu
	▼	Program Down / down in the menu
	◀	Decrease volume / to the left in the menu
	▶	Increase volume / to the right in the menu
	OK	**Show channel list / confirm menu item**
10	**INFO**	Shows information on the current program
11	**FAV**	Shows favorite program list
12	◀◀ ▶▶	Fast forward and backward
13	⏮ ⏭	Jump forward and backward
14	**USB**	Opens Personal Planner
15	🔇	Mute
16	**16:9**	Toggle video format
17	**AUDIO**	Change audio mode
18	**RECALL**	Switch back to the last viewed program
19	**+/-**	Program +/-
20	●	Yellow function key
21	●	Blue function key
22	**EXIT**	Exit menu or menu item
23	**BACK**	Back to the previous menu item
24	**EPG**	Opens electronic program guide (EPG)
25	**TXT**	Opens / close teletext
26	●	Starts direct record
27	⏯	Starts / pause playback
28	■	Stops record / playback

No.	Key	Description
29	**HELP**	Opens the support area of the smart website [2]
30	**PVR**[3]	Opens data storage menu

2.4 Save Energy

The Zappix HD+ receiver is equipped with special energy-saving electric and electronic components. Moreover, a well thought-out energy management will help you save energy.

The Save Energy standby mode will reduce the power consumption to less than 0,5 Watt (energy mode economic, see section 7.5.1, page 71)!

2.5 Warranty

The warranty for the HDTV satellite receiver smart Zappix HD+ complies with the legal regulations at the time of purchase.

3 Safety Instructions

3.1 Designated Use

The HDTV Satellite Receiver smart Zappix HD+ is intended for the reception of both, free to air and scrambled digital satellite programs (DVB-S/S2) in the private sector. It is designed exclusively for this purpose and may be used only for this.

Any other use is not considered as to be designated. We will not be liable for damage caused by any use contrary to the designated use.

[2] Only available with plugged in smartPORTAL-Stick PX1 and properly configured WLAN connection

[3] PVR = Personal Video Recorder, hard disk recorder for digital recording of audio and video

3.2 Hazards during designated use

CAUTION!

WARNING!

Possible malfunction or unit damage caused by moisture, wrong mains voltage and/or wrong mains frequency, lightning or mechanical overstraining.

Hazard of electric shock by contact with line voltage.

- Ensure that receiver and mains plug as well as the rcu do not come into contact with any moisture whatsoever.
- Connect the receiver to 175…250 V ~, 50/60 Hz only.
- During an electric storm or operational faults, pull the plug.
- Do not place any heavy objects on the receiver.
- Do not bend or squeeze the cable.
- Repairs on plug, cable or receiver may only be performed by qualified skilled personnel.

3.3 Grounding

The satellite antenna must be grounded properly. Note the relevant VDE[4] regulations[5].

smart recommends that the outdoor unit of the satellite system should be installed by a professional!

3.4 Location

- Place the receiver onto a solid and level surface.
- Protect the receiver from humidity, heat, dust and dirt.

[4] VDE = Verband der Elektrotechnik, Elektronik, Informationstechnik (German) = Association for Electrical, Electronic & Information Technologies

[5] DIN EN 60728-11 VDE 0855-1:2011-06: Cable networks for television signals, sound signals and interactive services, Part 11: Safety

- ➢ Do not place items filled with liquid, e.g. flower vases, onto the receiver.
- ➢ Protect the receiver from dripping and splash water.
- ➢ Do not place burning items, e.g. burning candles, onto the receiver.
- ➢ Ensure sufficient ventilation (ventilation slots must not be blocked): the receiver should have a distance of at least five centimeters to its surrounding elements on all sides.
- ➢ Ensure that the ventilation openings are not covered by objects such as newspapers, table cloths, curtains etc.
- ➢ Only operate the receiver in moderate climate (not in tropical climate).
- ➢ Place the receiver so that the mains plug can be disconnected at any time, correspondingly disconnecting the device from the mains.

If the device is transported from cold to hot environment, then condensing humidity may build up in the device.

➢ Do not connect the device, but leave it switched-off for some hours.

3.5 Proper Handling of Batteries

- Batteries must be kept away from children.
- Leaking batteries may cause damage to the environment and the remote control.

➢ Batteries must be disposed of in accordance with current legal regulations (see chapter Disposal, page°98).

3.6 Product Liability

We do not assume liability, if the designated protection of the unit is impaired, especially in these cases:

- The unit is not used according to the manual.
- The application range is not correct.
- The user makes unauthorized changes regarding the receiver hardware .

4 Connecting the Zappix HD+

4.1 Connection Diagram

After mounting the outdoor unit, connect the ports of your satellite receiver according to the following wiring diagram.

CAUTION!

- Connect the receiver first to the antenna and then to all other devices, before plugging the mains plug into the socket.
- Pay also attention to the respective notes in the manuals of the other devices.
- Make sure the cables are routed so, that you cannot step on them or stumble over them.



4.2 Connecting the Satellite System

- Connect the cable of the satellite system to the **LNB IN** socket.

The satellite signal at the LNB IN connection is looped through the receiver and can be tapped at the LNB OUT connection, to connect, if desired, additional receivers.

If your receiver is in standby mode, you only can use loop through if you selected the energy mode economic (see section 7.5.1, page 71).

4.3 Connecting the TV Set

As shown in the connection diagram, there are various options to connect the smart Zappix HD+ and the TV set. It depends on the connectivity of your TV set which option is possible for you.

Is there a HDMI socket at the TV set?		
YES	**NO. Choose one of below possibilities.**	
		
➢ Connect TV set and receiver with a HDMI cable.	➢ Connect TV set and receiver with a scart cable.	➢ Connect TV set and receiver with a single-pole composite video cinch cable and a double-pole stereo cinch cable.

➢ If your TV-Set has all these sockets, always choose the connection via HDMI cable.

Quality is best, if both, audio transmission and video transmission is digital.

4.4 Connecting a Home Theater System (optional)

In order to improve the sound quality, you can connect to your Zappix HD+ additionally to the TV set, a home theater system with surround sound or a stereo system. Once more, there are various options. It depends on the connectivity of your home theater system which option is possible for you.

a.

Your home theater system can loop through the HDMI signal, i. e. there is a HDMI socket to connect the receiver and a HDMI socket to connect the TV set.

➢ Connect the home theater system and the receiver with a HDMI cable and connect the home theater system with your TV set with another HDMI cable.

b.

Your home theater system can process digital audio data – there is a digital audio socket.

➢ Connect your home theater system and your receiver with an optical cable or a single-pole cinch cable.

c.

Your home theater system cannot process digital audio data – there is no digital audio socket.

➢ Connect your home theater system and your receiver with a double-pole cinch cable (stereo).



☞

➢ If your home theater system (or stereo system) has all these sockets, always choose the connection via HDMI cable.

Quality is best, if both, audio transmission and video transmission is digital.

4.5 Connecting a Data Storage Device (optional)

➢ Connect the receiver via the USB socket to a data storage device (USB stick or hard disk with USB socket) with a suitable cable. Then you can

- store video recordings (see chapter ***PVR***, page 47) or
- access various media files (see section ***Media Player***, page 62).

4.6 Connecting a Home Network (optional)

➢ Connect via the receiver's USB socket the smartPORTAL-Stick PX1, in order to connect the receiver to your home network / to the internet.

➢ How to configure a wireless connection is described in section 7.5.6 on page 78.

4.7 Connecting the Power Supply

➢ Plug mains plug into socket, when all devices have been properly connected to the receiver:

4.8 Inserting the Batteries of the RCU

This is the procedure to insert new RCU batteries or to replace empty batteries:

➢ Open the battery cover at the bottom of the RCU.

➢ Insert two batteries 1.5 V (Type: AAA).

Take care of the right polarity!

➢ Replace batteries when the range of the remote control is decreasing or when the receiver no longer reacts to all commands.

➢ When not used for prolonged periods of time, batteries may leak. Remove batteries from the remote control if it is not used for long periods of time (> 1.5 years).

➢ When replacing batteries, always replace all batteries.

5 Basic Operation

This chapter describes the necessary steps to use easily the radio and television programs broadcasted via satellite.

5.1 Switching on the Receiver

1. Ensure that you chose the right AV input at your TV set (i. e. that the receiver signal will be displayed).

2. Ensure that you chose the right audio input at your home theater or stereo system.
3. Switch on all connected devices.
4. Switch on the receiver with the mains switch on the rear panel (I, ON).

   The receiver boots up. For a short time the smart welcome screen is displayed, then the first installation window. You see “WELCOME” in the receiver display. Now, you can choose the **menu language.**

5. If you don’t want to take over the default value Deutsch for the menu language, proceed like this:



   – Press the key ▶, in order to go to the options.
   – Choose the desired language with the keys ▲ and ▼.
   – Press **OK**, in order to confirm the chosen language.
   – Press the **green function key**, in order to go to the next installation window.

6. In the second installation window you can select whether you want to install the receiver with or without smart RAPS[6]:



   1. Press the key ▶, in order to go to the options.
   2. Select the desired installation with the keys ▲ and ▼. Possible are:
      - RAPS
      - Automatic (HD+)
      - Satellite Search
      - Predefined List

5.2 Installation with RAPS

Your smart Zappix HD+ is equipped with RAPS. RAPS means **R**eceiver **A**utomatic **P**rogramming **S**ystem and works like this:

[6] RAPS = Receiver Automatic Programming System, see section 5.2

Always when you switch off your receiver, RAPS is looking for changes in the channel lists. This takes only a few seconds. If there are any, the new data will be taken automatically as new channel list. If the channel parameters of a program will be changed, RAPS will take over these automatically.

If there are new programs, these will be added. If programs are switched off forever, the channel list positions will be deleted. New programs will not simply be added but divided in logical blocks in order to allow fast find.

For example for Germany there are a basic list and additionally the groups 3rd programs, info and sports, special interest, local TV, news (beginning position 100) and many music channels (beginning position 123).

After you selected *RAPS*:


Help message
The receiver will install RAPS within the next 3 seconds. It is necessary that you receive signal from Astra 19.2° East. If you can t receive Astra 19.2° East, please press <Exit> on your remote control.
Antenna settings
Satellite1 19.2°E ASTRA 1F,H,KR,L,M
Satellite2 Not assigned
Satellite3 Not assigned
Satellite4 Not assigned

1. Press **OK**, in order to confirm the chosen installation type.
2. Press the **green function key** (continue)., in order to go to the next installation window.

   The third installation window **Antenna Settings** starts the RAPS installation. You only have to wait 10 seconds. The installation begins with a „DiSEqC scan“, searching through the antenna signal for receivable satellites.

   Press the **green function key (continue)**.after the search for satellites is completed.

➢ Note that for the RAPS installation you must be able to receive signal from Astra 19.2° East.

The next window displays the found satellites (marked with +):

3. Press the **green function key (continue)**, in order to take over these satellites

   or

   select more satellites with the keys ▲ and ▼ (of course, you should know that they are receivable) and confirm each with **OK**, then press

the **green function key** (continue) **or**
press the **yellow function key (select all)**, in order to select all satellites, then press the **green function key (continue)**.
In the next window you should select your country (respectively the country, where the receiver is operated).



4. Select the country with the keys ▲ and ▼ and press the **green function key (continue)**, in order to confirm and to go to the next window, where you can select your preferred regional program (“3rd program“).



5. Select the desired program, whose position should be 3 in the channel list, with the keys ▲ and ▼ and press the **green function key (continue)**, in order to confirm and to go to the next window Channel - Filter, where you can select, whether you want to add erotic programs and call TV to your channel list. Both offers may cause high telephone costs.



6. Select erotic and call TV with the keys ▲ and ▼ and confirm each with **OK**, in order to add erotic programs and call TV to your channel list (mark with +). Then press the **green function key (continue)**, in order to go to the next window Subscription packages. You are asked, whether pay TV providers should be added to the channel list:



E. g. if you select HD+, the SD channels will automatically be exchanged with the corresponding HD channels, i. e. the HD channels



are located in the channel list, where you normally find the SD versions (e. g. RTL at pos. 4) and the SD channels are located at pos. 333 and the following.

If you do not select the pay TV package, the SD channels are at the beginning of the channel list (e. g. RTL at pos. 4), the HD versions of these channels are not anymore included in the channel list.

By default HD+ is activated. Press **OK**, in order to deactivate HD+. Press **OK** once more, in order to activate HD+ again.

If you first choose HD+ channels, but do not want them later, you have to perform a new RAPS configuration deselecting the pay TV package.

7. Press the green function key (continue), in order to start the installation of the channel list. When the installation is complete the receiver switches automatically to TV mode.

5.3 Installation without RAPS

5.3.1 Predefined List

➢ Select **Predefined List** and press **OK**, in order to take over the **predefined list** or an empty list.

  ➢ Press the green function key (continue).

  ➢ In the next window select with the keys ▲ and ▼ one of these options: *Standardliste*: *Default List*
  Default, the receiver contains a simple channel list with a small number of channels.
  or
  Blankoliste: *Plain List*,
  Channels have to be added manually (e. g. by performing a **Channel Search**, see section 7.5.7, page 80).

➢ After pressing **OK** the receiver switches to TV mode.

If you selected Plain List, the screen remains black, because there is not yet a filled channel list.

➢ Select **Satellite Search** and press **OK**, in order to perform a scan over all satellites and find all receivable channels and to add them to the **All Channels Lists** (“Gesamt TV”, “Gesamt Radio”). The next steps are the same as described under item 2 in section 5.3.2.

5.3.2 Automatic (HD+)

1. Select **Automatic (HD+)** and press **OK** and then the **green function key (continue)**, in order to download the HD+ channel list. You‘ll get the menu window **Antenna Settings**, where you can select the satellites from which you want to receive programs.
2. Select with the keys ▲ and ▼ the items *Satellite1*, *Satellite2*, *Satellite3* or *Satellite4* (you can select maximum four receivable satellites). Change with the key ▶ to the right side of the window. Select there with the keys ▲ and ▼ the desired satellite and confirm with **OK**
   or
   Press **Auto detect** (yellow function key), in order to search for satellites automatically.
   The satellite search starts. On top of the menu window there occurs a progress bar. Wait until the satellite search is completed.
3. Press the **green function key** (continue), in order to start a channel search. Wait until the channel search is completed.
4. Press the **green function key** (continue), in order to accept the HD+ channel list.
5. Press the **green function key** (continue) after the channel search is completed, in order to save/confirm the found channels.

5.4 Software Update

Once you have put your Zappix HD+ into operation, you should first update the operating software of your receiver!

5.4.1 Update via USB

You can transfer the current software via the USB interface:

1. Look for the update file on the website www.smart-electronic.de (item Support → Zappix HD+ → Download).
2. Save the file to your PC.
3. Unpack the file, which is a .zip archive.
4. Copy the new software file (30-35 MB) on a USB storage device. Do not rename the file after unpacking.

- Ensure that the update file (idl5k.bin) is included directly in the root directory of your USB storage device (**no subdirectory**)**!**
- Do not rename the unpacked file!

5. Switch off your receiver (with the mains switch at the rear panel).
6. Plug in the USB storage device.
7. Switch on the receiver via the mains switch and press at the same time the key ▲- at the front panel.
   The text in the receiver's display is „WAIT" and then „LOAD". On the TV screen you see the smart logo and a progress bar.
   The update needs about one minute. After the update normal operation is started automatically.
8. After the update, reset the receiver to factory defaults (section7.5.8, page 81).

5.4.2 Online Update

Together with a **smartPORTAL-Stick PX1** you can update your device directly over the Internet.

Please, ensure that your device is properly connected to the Internet. For more information on cabling and the right settings, see the instructions in the sections ***Connecting a Home Network*** on page 21 and ***Network*** on page 78.

1. In TV mode press **MENU**.
2. Select the menu **Control Panel**.
3. Select the submenu System Update and follow the instructions on the screen.
4. After the update reset the receiver to factory defaults (section 7.5.8, page 81).

5.4.3 OTA[7] Update

Updating the software is also possible via satellite.

Attention!

Updating the software via satellite can need up to more than one hour.

When there is a connection to the internet or an attached USB storage device contains a valid update file, the receiver will not be updated via satellite, but online (internet) or via the USB port (see above).

Please ensure, that you can receive Astra 19.2° east.

1. In TV mode press **MENU**.
2. Select the menu **Control Panel**.
3. Select the submenu **System Update** and follow the instructions on the screen.
4. After the update reset the receiver to factory defaults (section 7.5.8, page 81).

5.4.4 Automatic Update

The receiver also checks in subsequent operation continuously, whether online or via satellite a newer software file than the already installed is available.

[7] OTA = **O**ver **T**he **A**ir = via satellite

5.4.4.1 Update During Operation

If new software is available you'll get a corresponding message a few minutes after turning on the receiver:

➢ Select *Confirm* to

a) load the new software from a connected USB storage device and then install it,

or

b) to download the new software from the internet without USB storage device but with an active internet connection and then install it

or

c) to download the new software from the satellite Astra 19,2° east without USB storage device and without active internet connection and then install it.

Attention!

Updating the software via satellite can need up to more than one hour.

Therefore now a solicitation appears to plug a USB disk. The further procedure is as described in the following section.

➢ Select *Cancel event*, if you do not want to update now.

5.4.4.2 Update During Standby-Mode

Since updating the software via satellite can need up to more than one hour, you can download the update file Zappix HD+ in standby mode and save it to a connected USB storage device.

The actual update is carried out from the USB device when you switch on the receiver the next time (see section 5.4.4.1 a). It takes only one minute or two.

5.5 Operation Mode

The operation mode after the first switch on (or after restoring the factory settings) is television (TV).

When you switch-on the receiver after it was off, the mode is always the selected prior to switch-off.

You can select the modes TV (television programs) and radio (radio):

- Press the key **TV/R** on the remote control. Following window appears:



- Select with the keys ▶, ◀, ▲ and ▼ the valid channel list:
  - Select *Gesamt TV*, in order to set the TV mode.
  - Select *Gesamt Radio*, in order to set the Radio mode.
  - Select an own list (here *Meine Favoriten 1*), in order to define a favorite list as basis for the further operation (Radio or TV).
- Press **OK**, in order to confirm your selection.
  The window disappears and you see or hear the first channel of the selected channel list.

In order to keep descriptions simple, we will assume "normal" TV mode.

The menu operation is basically independent from the operation mode (Radio or TV).

5.6 Open/Close Menu

Your smart receiver is operated via an OSD (OnScreenDisplay).

- Press the key **MENU** (of the remote control or at the receiver) in order to open the menu:

If you open the menu during watching TV, the first menu window is always the one shown above.

➢ Press the key **EXIT**, in order to close the menu again.

5.7 Menu Navigation

You can navigate in the menu with the keys on the remote control as well as with the keys at the receiver.



receiver *remote control*

➢ Press ▲, in order to go to the menu item above.

➢ Press ▼, in order to go to the menu item below.

➢ Press ▶ and ◀, in order to go to the menu item right or left or to change a selected value.

➢ Press **OK**, in order to select a menu item or to confirm a set value.

➢ Press **BACK**, in order to go to the previous menu item.

Menu items that are active are highlighted in color.

If there are more values in a list than what is displayable, you will get additional symbols at the top and at the bottom, which indicate, that the list is longer than you can see.



list goes on at bottom.

list goes on at top.

5.8 Watching TV

5.8.1 Channel Selection

- Select with the keys ▲ / **P+** and ▼ / **P-** the channel which you want to see
  or
- Type the channel list position of the desired channel via the numeric keys of the remote control and confirm with **OK**
  or
- Press **OK**, in order to open the window **Quick view**.



Following is displayed:

- The currently used channel list (here *Gesamt TV*).
- A thumbnail of the current channel.
- Detailed info about the current program in the upper part of the window.
- At the bottom of the window there are four function keys in order to access enhanced functions.

- Press the keys ▲ and ▼, in order to navigate through the channel list and to select a channel (the selected channel is highlighted).
- Press **OK**, in order to switch to the selected channel (this channel will be shown in the thumbnail view).

➢ Press the keys **P+** and **P-**, in order to move eight positions in the channel list up or down.

5.8.2 Select Channel List

1. Press the key **FAV** (on the remote control), in order to open the window **Choose default list**:

2. Press the keys ◀ and ▶ in order to select the channel list, which you want to define as standard for further operation.
3. Press **OK**, in order to confirm your selection and to close the window.

From now on the selected list will be displayed when you press **OK** in TV mode (see section 5.8.1).

5.8.3 Recall

➢ Press the key **RECALL** of the remote control in order to switch to the previous channel.

5.8.4 Teletext (Videotext)

Teletext (or "broadcast teletext", in Germany “Videotext”) is a television information retrieval service. To receive teletext the broadcast station must support this function.[8]

➢ Press the key **TXT** of the remote control, in order to switch on teletext. The first teletext page 100 is displayed.

When you switch on teletext the first time your receiver loads and saves maximum 1800 pages (incl. all sub-pages), which then can be accessed very fast. The number of already loaded teletext pages is displayed at the bottom left side. The page memory will be cleared if you switch to another channel.

[8] Teletext information is broadcast in the vertical blanking interval between image frames in a broadcast television signal.

This way you can navigate between teletext pages:

Key	Function
▲ or the **green function key**	next main page
▼ or the **red function key**	previous main page
▶	next subpage or next main page if there are no or no more sub pages
◀	previous subpage or previous main page if there are no or no more sub pages
yellow function key	opens the start page 100
blue function key	opens page 200 (content is channel dependent)
Menu key	switches the view of teletext : • normal (normal, teletext is displayed all over the TV image) • small (reduced size, about 1/6, displayed top left) • half (reduced size on half of the screen)

When Teletext is activated the arrow keys (▲/▼/◀/▶) can only be used for navigation. The volume control is only possible via the keys **+** and **-**.

➢ Press the key **EXIT** or once more the key **TXT**, in order to switch off teletext again.
Now, the volume can be changed again via the arrow keys ◀ and ▶.

5.8.5 Quick Access Menus

➢ Press the key **INFO**.

You see the **info window** with details about the current channel:



No.	Function
1	Press the keys ▲ and ▼, in order to switch to the previous or next channel.
2	Logo of the current channel
3	Position of the current channel in the channel list
4	Name of the current program
5	Name of the current channel
6	Beginning and end of the current program
7	USB storage device is connected
8	Receiver is connected to a LAN via a wired connection.
9	The current channel is included in a RAPS channel list.
10	Name of the following program
11	Current day, date and time
12	Signal strength
13	The current channel provides HbbTV
14	Press the key ◀ in order to go to the previous quick access menu.
15	The current channel is broadcasted with legacy resolution SD (Standard Definition) or with high resolution HD (High Definition).
16	The current channel is included in a favorite list (the standard channel list is also considered as a favorite list).
17	The current program provides subtitles.
18	The current channel is broadcasted in legacy 4:3 format 4:3 or in 16:9 format 16:9.

No.	Function
19	For the current program various languages / different audio modes are available.
20	The current channel is broadcasted with legacy stereo sound or in Dolby Digital.
21	The current channel is locked / not locked (parental control).
22	The current channel is receivable freely[9].
23	The current channel is broadcasted with Teletext.
24	Indication of pressing the red function key to show HbbTV messages and HbbTV content.
25	Graphical representation of the sequence of the current program.
26	Indication of pressing the yellow function key to directly access the smartPORTAL.
27	Indication of pressing the blue function key to directly access the sorting function.
28	Beginning and end of the following program.
29	Press ▶, in order to go to the next quick access menu.

➢ Press the keys ◀ and ▶, in order to go to the various quick access menus:

☞

➢ Press the key **INFO** during TV mode or Radio mode, in order to open the info window any time.

➢ The info window is automatically closed, but you can also Press the key **EXIT**, in order to close it manually.

◀	▶
Add to favorite	**Mini Guide**[10]
Subtitles	**Full Guide**
Aspect Ratio	**Personal Planner**
TV Resolution	**List Manager**
Soundtrack	

[9] FTA = Free To Air, the channel is broadcasted without scrambling
[10] EPG = Electronic Program Guide = electronic program guide, electronic program magazine

◀	▶
Audio	
Sleep Timer	
Parental Control	

The quick access menus correspond partly to the ‘normal‘ menus as explained below, but in some cases the functional range is restricted. Therefore, these menus are easier to operate.

Example:

In the quick access menu **Add to favorite** you add simply the current channel to a favorite list by pressing **OK** two times.

5.8.6 Adding a channel to a favorite

1. Press the keys **INFO** and one time ◀, in order to go to the window **Add to favorite**.
2. Press **OK**, in order to select the first favorite list.
3. Press the keys ◀ and ▶, in order to select the favorite list, to which you want to add the current channel and confirm with **OK**.
4. Press **EXIT**, in order to go back to the TV mode.

5.8.7 Subtitles

If the current channel contains subtitles in different languages you can select the desired subtitles in the quick access menu **Subtitles**.

1. During watching TV, press the keys **INFO** and two times ◀, in order to go to the quick access menu **Subtitles**.
2. Press **OK**, in order to select the first option
3. Press the keys ◀ and ▶ in order to select between the different options and confirm with **OK**.
4. Press **EXIT**, in order to go back to the TV mode.

5.8.8 Aspect Ratio

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **Aspect Ratio**.

2. Press **OK**, in order to select the first format.
3. Press the keys ◀, ▶, ▲ and ▼, in order to select the desired format. Possible values are:

Value	Meaning	
4:3 Automatic	4:3 TV set	Independently from the current program you do not lose any image information.
4:3 Pan & Scale		• 4:3 programs are displayed optimal. • 16:9 programs: the image size is changed in order to fit the screen height, at both sides right and left, there is image information missing.
4:3 Letter/Pillar Box		• 4:3 programs are displayed optimal. • 16:9 programs: the image size is reduced in order to fit the screen width; a lack of height is filled up by black bars.
16:9 Automatic	16:9 TV set	Independently from the current program, you do not lose any image information.
16:9 Pan & Scale		• 4:3 programs: the image size is changed in order to fit the screen width, at top and bottom, there is image information missing. • 16:9 programs are displayed optimal.
16:9 Letter/Pillar Box		• 4:3 programs: the image size is reduced in order to fit the screen height; a lack of width is filled up by black bars. • 16:9 programs are displayed optimal.

4. Press **OK**, in order to confirm your selection.
5. Press **EXIT**, in order to go back to the TV mode
   or
   change to another quick access menu.

Sometimes there are programs on the HD+ channels in 4:3 format, where you cannot change the aspect ratio!

Beside the quick access menu **Aspect Ratio**, you can also change the aspect ratio directly via the key **16:9** of the remote control. The current setting is displayed on the receiver:

Display	Meaning
4/3 A	*4:3 Automatic*
4/3 C	*4:3 Center Cut-Out = 4:3 Pan & Scan*
4/3 L	*4:3 Letter/Pillar Box*
16 L	*16:9 Letter/Pillar Box*
16 C	*16:9 Center Cut-Out = 16:9 Pan & Scan*

5.8.9 TV Resolution

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **TV Resolution**.
2. Press **OK**, in order to select the first resolution value[11].
3. Press the keys ◀, ▶, ▲ and ▼, in order to the highest value your TV set can show.

Value	Order
1080p[12]	Highest value
1080i	↓
720p	↓
576p	↓
576i	Smallest value

4. Press **OK**, to confirm your selection. Now, you can change to another quick access menu.
5. Press **EXIT**, in order to go back to the TV mode.

If your receiver and your TV set are connected via Scart, the maximum resolution 576i.

[11] Vertical resolution in lines
[12] p = progressive, i = interlaced

Beside setting the resolution via the menu, you can also change the resolution directly via the remote control:

- Press the key **V-Format** (perhaps several times), in order to change the video resolution at the HDMI output. The current setting is displayed on the receiver You can set these values:

Display	Value
576P	*576p*
720P	*720p*
HD I	*1080i*
HD P	*1080p*

5.8.10 Soundtrack

If a program is broadcasted with multi-channel tone, you can select a language in the quick access menu **Soundtrack**.

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **Soundtrack**.
2. Press **OK**, in order to enter the menu and to select the language Deutsch.
3. Press the keys ◀, ▶, ▲ and ▼, in order to select the desired language and press **OK**, in order to confirm your selection. You can change now to another quick access menu.
4. Press **EXIT**, in order to go back to the TV mode.

5.8.11 Audio

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **Audio**.
2. Press **OK**, in order to select the audio mode.
3. Press the keys ◀, ▶, ▲ and ▼, in order to select the best value for the current program.

Mode	Meaning
Dolby Digital	At the receiver outputs the encoded Dolby Digital audio signal is available (for items that are broadcast with Dolby Digital sound).

Mode	Meaning
Stereo	Both the left and right stereo channels are available at the receiver outputs.
(Links)	The left audio channel of a program is available at both receiver outputs (e. g. for bilingual broadcasting).
(Rechts)	The right audio channel of a program is available at both receiver outputs (e. g. for bilingual broadcasting).

4. Press **OK**, in order to confirm your selection. You can change now to another quick access menu.
5. Press **EXIT**, in order to go back to the TV mode.

5.8.12 Sleep Timer

The Zappix HD+ has a sleep timer that allows that the device automatically goes to the standby mode (standby). You can

- set the time manually **or**
- select one of the given time intervals.

You can also switch off a programmed or already active timer.

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **Sleep Timer**.
2. Press **OK** or ▼, in order to enter the menu.

Now you have various options:

a) Manual Entry:

The maximum time interval you can set manually is 23:59

1. Press the keys ◀ and ▶, in order to select *Set Time Manually*.
2. Press **OK** to open the window **Set Time Manually**.
3. Press **OK** once more, in order to activate the entry of the hours and set them with the keys ▲ and ▼.
4. Press ▶, in order to go to the entry of the minutes and set them with the keys ▲ and ▼.
5. Press **OK**, in order to confirm your entries.

6. Press **EXIT**, in order to go back to the TV mode.

b) Select from the Given Time Intervals:

1. Press the keys ◀ and ▶, in order to select the desired time interval.
2. Press **OK**, in order to confirm your selection to activate the timer. You can change now to another quick access menu.
3. Press **EXIT**, in order to go back to the TV mode.

c) Deactivate the Timer:

1. Press the keys ▲ and ▼ in order to select the key **Off**.
2. Press **OK**, in order to confirm your selection. You can change now to another quick access menu.
3. Press **EXIT**, in order to go back to the TV mode.

5.8.13 Parental Control

When enabled in Settings / Parental blocking channels, you can simply edit the list of blocked channels.

1. Press the keys **INFO** and several times ◀, in order to go to the quick access menu **Parental Control**.
2. Press the keys ◀ and ▶, in order to decide, whether you want to block or deblock the current channel.
3. Press **OK**, in order to confirm your selection. You can change now to another quick access menu.
4. Press **EXIT**, in order to go back to the TV mode.

5.8.14 Mini Guide

The Electronic Program Guide (EPG) is a convenient substitute for a printed program guide. You can also use EPG to program records easily. The Zappix HD+ offers two EPG versions.

➢ Press the keys **INFO** and one time ▶, in order to open the window **Mini Guide**:



No.	Meaning
1	Name of the current channel list
2	EPG original time (first time mark)
3	EPG day and date
4	Next full hour after the original time (second time mark)
5	Second program of the current channel
6	Third program of the current channel
7	Third time mark (second time mark + 30 minutes)
8	Current day, current date and current time
9	Fourth time mark (third time mark + 30 minutes)
10	Logo of the current channel
11	Logo of the next channel in the channel list
12	Position of the current channel in the channel list
13	Position of the next channel in the channel list
14	Name of the next channel in the channel list
15	Name of the current channel
16	Name of the current program
17	Name of the current program of the next channel
18	Second program of the next channel
19	Third program of the next channel
20	Fourth program of the current channel

- If you are in the window **Mini Guide** you can access further functions:
- Press **OK**, in order to get detailed information about the current program and in order to get access to following functions:
  - Press the keys ▶ and ◀, in order to scroll forward or backward.

➢ Press the keys ▲ and ▼, in order to get detailed information about the current program and then, after pressing the keys once more, to get EPG data for all channels of the current channel list.

☞ If the existing text in the detailed information cannot be displayed at once, an automatic scrolling process starts after 3 seconds.

5.8.15 Full Guide

➢ Press the keys **INFO** and two times ▶ or press **EPG** on the remote control, in order to go to the window **Full Guide**.

Wed 08 May, 14:15 Land und lecker (1)
Wer kocht das beste Landmenü?
Sechs Bäuerinnen aus unterschiedlichen Landschaften stellen die Kochkünste unter Beweis. Eine lädt ihre Kontrahentinnen zu einem Drei-Gänge-Menü auf den Hof ein. Und am Ende steht die Frage: Wer hat das beste Landmenü zubereitet? Corinna Ebsen lebt mit Mann Oke, drei Kindern, den Schwiegereltern und vielen Rindern, Schweinen und Hühnern im nordfriesischen Langenhorn. Zum Dinner gibt es selbst
Full guide
Wed 08 May, 14:52
Gesamt TV
14:52 Wednesday May, 08 15:00
15:30
16:00
1 Das Erste HD
2 ZDF HD
3 BR Nord HD
4 RTL HD
5 Sat 1 HD
6 Vox HD
7 Prosieben HD
8 arte HD
Rote R...
Tagesschau
Sturm der Liebe (1754)
Die Kü...
heute
Topfgeldjäger
Land...
Bergbauern - wie's weitergeht
Wir in Bayern
Die Tr...
Verdachtsfälle
Auf St...
Familien-Fälle
Verkla...
Shopping Queen
The Big Bang Theory
The Big Bang Theory
How I Met Your Mother
Die Spieler
Quick view
Single channel
Sorting
More options

The window **Full Guide** is similar to the window **Mini Guide** and you can operate it in the same way. The main difference is that it shows eight channels at the same time. Additionally there are four function keys at the bottom, which offer more features. You can also open the window **Full Guide** via the main menu (Guide).

If you are in the window **Full Guide** you can access further functions:

➢ Press **OK**, in order to open a window with detailed information about the current program and to access the following functions.

➢ Press the keys ▲ and ▼, in order to view the EPG data of all channels in the current channel list.

- Press the keys ▶ and ◀, in order to switch inside one channel from one program to the other.
- Press the **red function key**, in order to switch between the window **Quick view** and the window **Full Guide**.



- Press the **blue function key**, in order to open the window **More options**:

The possible display and edit functions are explained in section ***EPG More Options***, on page 7.7.

- Press the **green function key**, in order to switch between **Full Guide** and **Single Channel**.
  The window **Single Channel** only shows the programs of one channel:

Fri 10 May, 09:30 Primal Grill - Grillen für Profis
Entwicklungssprung in der Barbecue-Evolution dar. Die weltweite Beliebtheit von Kebab und Satè zeugt vom ungebrochenen Reiz aufgespießter Speisen. Umso ärgerlicher sind Kebabs auf Bambusspießen mit angekokelten Enden sowie Metallspießen mit rohen Zwiebeln und verbratenem Fleisch. Wer jemals Schwierigkeiten beim Aufspießen eines Shish Kebabs hatte oder einfach nur sein Barbecue-Repertoire erwe
64 RTLNITRO
Fri 10 May, 09:49
09:30-09:55 Primal Grill - Grillen für Profis
09:55-10:20 Primal Grill - Grillen für Profis
10:20-10:50 Primal Grill - Grillen für Profis
10:50-11:15 Hairy Bikers US
11:15-11:40 Hairy Bikers US
11:40-12:05 Hairy Bikers US
12:05-12:30 Hairy Bikers US
12:30-13:00 Hairy Bikers US
13:00-13:25 Auf der Suche nach dem perfekten Genuss
Quick view
Full guide
More options

➢ Press **EXIT**, possibly several times, in order to close all EPG windows and to go back to the TV mode.

5.8.16 Personal Planner

The **Personal Planner** which is available via the key **INFO**, is the same as the **Personal Planner** explained in section 7.1.8 on page 55.

5.8.17 List Manager

The submenu **List Manager** which is available via the key **INFO**, is the same as the **List Manager** explained in section 7.1.9 on page 58.

5.9 HbbTV[13]

With plugged in **smartPORTAL-Stick PX1** and properly configured WLAN connection your Zappix HD+ allows you to use the various HbbTV offers of the broadcast stations.

For that purpose you need to proceed as follows:

1. Ensure that, beside the connection to the SAT antenna, your receiver is connected to the internet. How to connect your receiver to a home network and thus to the internet is described in the sections 4.6 on page 21 and 7.5.6 on page 78.
2. Press the **red function key** in order to view the HbbTV notification.

[13] HbbTV = Hybrid Broadcast Broadband TV, linkage between TV and internet content

The HbbTV notification will only be displayed, if the current channel is broadcasting HbbTV content.

3. Press the **red function key** once more in order to view the HbbTV content. Now you can, depending on the broadcast station, access other functions, mostly via the colored function keys.
4. Press the **red function key** again in order to hide the HbbTV content.

➢ If you want to access the menu, you must leave HbbTV completely. For that purpose, press **EXIT**!

6 PVR

6.1 Record

There are three options, to use the personal video recorder with an external USB disk to record TV and radio programs:

First, connect an USB disk to the USB port at the rear panel of the Zappix HD+ and wait until it is detected by the receiver.

For a short time the info window (section 5.8.2) will be displayed, extended by a disk icon.



You will find adequate USB sticks and external hard disks in the **smart** accessory shop on www.smart-electronic.de.

Note that if you have a disk divided into multiple partitions you first must specify the default folders for record and timeshift (see section 7.1.4, page 53)!

➢ Press **REC** during watching a TV program (Quick Shot)
or

- Select programs in the EPG screen and add them to the **Personal Planner** (see section 6.2, page 48)
  or
- Schedule a record directly in the **Personal Planner** (see section 7.1.8, page 55).

The storage requirements for records are approx. 40 MB per minute (2.5 GB / hour) for SD records (standard resolution) and approx. 120 MB per minute (7.0 GB / hour) for HD records (high resolution).

The records are stored in .TRP format. There a directory will be created which includes several files/streams (container). Of course, these files will be connected during playback.

The Zappix HD+ uses the FAT32 file system for records. It has a NTFS detection for playback.

6.2 Programming via EPG

From the EPG windows **Full Guide** and **Single Channel** you can directly access the **Personal Planner** event type window (see section 7.1.8, page 55) and schedule records, channel selection, or reminders.

- Press the keys ◀ and ▶ or ▲ and ▼, in order to select the program you want to record, you want to switch to, or about that you want to be reminded.
- Press **OK**. A new window is opened at the top.

1. Press the keys ◀ and ▶, in order to select under **Edit scheduled event** which event should be controlled.
   - Select **Record**, in order to schedule the record of the selected program.
   - Select **Tune**, in order to switch to the selected program, when that begins.
   - Select **Reminder**, in order to display a hint in the current program, when the selected program begins.
2. Press ▼, in order to go to To take place and to change the repeat mode.

Since it is easier to understand we will describe the settings only for the event Record.

- Select **Single**, in order to record the selected program only once.
- Select **Daily**, in order to record the selected program every day (at the same time).
- Select **Mon-Fri**, in order to record the selected program from Monday to Friday at the same time.
- Select **Weekly**, in order to record the selected program every week at the same day of the week.

3. Press ▼, in order to go to the button **Confirm**.
4. Press **OK**, in order to go back to the EPG window.

You cannot schedule recordings for programs which began in the past!

You can record a running program by pressing the key REC (starting a quick shot).

Press the key REC once more, in order to open a query window. Here you can

- stop the record immediately,
- stop the record after 15 minutes or
- create a link to the EPG.

Select the option Bind EPG, in order to stop the record at the end of the current program.

6.3 Time Shifting

If a storage device (USB disk, USB stick) is connected to the receiver, you can pause playback of the current program and resume it later at exactly the same position again.

- Press ⏯, in order to pause the current program (freeze frame) and to start the time shift record. For a short time the info window (section 5.8.5) will be displayed.

- Press ⏯ once more, in order to resume the playback of the current program.
- Press the keys ◀◀ and ▶▶, in order to go fast-forward and go fast-backward as you know it from your DVD player or video cassette recorder. Three different speeds are possible:

Display	Meaning
◀◀ or ▶▶	Fast forward / fast backward
◀◀◀ or ▶▶▶	Higher speed
◀◀◀◀ or ▶▶▶▶	Highest speed

Press the key ■, in order to go back to the currently broadcasted program.

6.4 Playback

There are different options for play back an USB recording:

6.4.1 Direct Playback

1. Press **PVR**, in order to open the window **All media**.
2. Press **OK** two times, in order to open the connected storage device. All files stored on the device will be displayed.
3. Press the keys ▲ and ▼, in order to select the recording you want to playback. Press **OK**, in order to open a subdirectory. If you open a file with **OK**, the movie will be played back in a preview window.
4. Press **OK** once more, in order to play back the movie in full screen mode.
5. Use the keys ◀◀ ▶▶, ⏯ and ■, in order to control the playback.

6.4.2 Playback via the Media Player

You can also playback USB recordings via the Media Player.

6.5 Recording one Channel and Watching another at the same Time

If you start a record with the key **REC** and then want to open the channel list with **OK**, you'll get such a message:


Information
You have on-going recordings or timeshift. In order to access the menu, you should stop recordings first.
Stop Recording
Cancel

However, during an on-going recording you can switch the screen to another channel broadcasted via the same transponder as the recorded channel:

➢ Press the keys ▲ and ▼ or the keys **+** und **–**.

> Note: the behavior of the receiver while recording may be modified by future software updates.

6.6 Recording and Playing EPG Data

During recording EPG Data is stored.

➢ Press **INFO** two times to show this information during playback.

> Note: the behavior of the receiver while recording may be expanded or modified by future software updates.

7 Extended Functions and Settings

This chapter explains all the commands that can be accessed from the menu. In addition, other features are described that haven't been mentioned yet.

7.1 TV/Radio

7.1.1 Live TV

➢ Select the submenu **Live TV** and press **OK**.
You see the first channel of the current TV channel list. For a short time the info window will be displayed (see section 5.8.5, page 34).

7.1.2 Live Radio

➢ Select the submenu **Live Radio** and press **OK**.
You see the first channel of the current Radio channel list. For a short time the info window will be displayed (see section 5.8.5, page 34).

➢ The info window disappears automatically. You also can press **EXIT**, in order to close it prematurely.

7.1.3 Recorded TV

In this submenu you can manage your recordings (movies). You can just display them (including preview), delete them or rename them.

You can also format the data storage device, mount and unmount the data storage device, and set default folders for record and time shift.

1. Ensure that you connected a data storage device to the receiver.
2. Select the submenu **Recorded TV** and press **OK**.
3. Press **OK** two times, in order to open the connected data storage device. All files stored on the device will be displayed.

➢ If you have not connected a data storage device, you'll receive an appropriate error message.

➢ Press the keys ▲ and ▼, in order to mark a file or a subdirectory.

➢ Press **OK**, in order to open the file or subdirectory.

If you are already in a subdirectory, you can select ***Up folder*** in order to go to the parent directory.

➢ If you open a file with **OK**, the movie will be played back in the preview window.

➢ Press **OK** once more, in order to play back the movie in full screen mode.

➢ For a short time an info window will be displayed:



No.	Meaning
1	Codec which was used during recording, record file format
2	Name of the recorded program
3	Date of the recorded program
4	Record resolution
5	Record file duration
6	Symbol for playback / pause (to be changed with the key ⏯)
7	Current date, time
8	Numerical indication of the current playback position
9	Graphical indication of the playback progress

- The info window disappears automatically. You can press **EXIT**, in order to close it prematurely.
- Press the **red function key** in the submenu **Recorded TV**, in order to delete a marked file.

With the delete function you can exclusively delete files. You cannot delete directories, even if they are empty

- Press the **yellow function key** in the submenu **Recorded TV**, in order to rename a marked file or directory.
  - Navigate to the left and to the right with the keys ▶ and ◀.
  - Delete characters with the **red function key**.
  - Add new characters by pressing – if necessary several times – the keys **0 … 9** of the remote control.

Example: press seven times the key **9**,in order to insert a small x.

7.1.4 Define default directories

- Press the **blue function key** in the submenu **TV/Radio / Recorded TV**, in order to define an open directory as default directory for

- Recording **or**
- Timeshift **or**
- Web Download.

You also can select **New Folder** in order to first create a new folder.

➢ Select the appropriate item with the keys ▶ and ◀ and confirm with **OK**.



➢ Press **EXIT**, in order to go back to the TV mode.

7.1.5 Formatting a storage device

➢ Press the keys ▲ and ▼ in the submenu **Recorded TV**, in order to go to **Up folder** and press **OK**. Following window opens:



In the upper part you see information regarding the USB storage device.

➢ Press the **red function key**. Following window opens:



Select with the keys ▶ and ◀ the desired file system (FAT32 – Windows or EXT3FS – Linux) or select **Cancel**.

For compatibility reasons smart recommends to use the file system FAT32. With FAT32 the maximum file size is 4GB. If a recording exceeds this size, the file will automatically be split in several parts.

7.1.6 Mounting/Unmounting an USB device

- Press in the **information window** above the **yellow function key (Unmount device)**, in order to unmount the storage device, before unplugging it. The meaning of the **yellow function key** changes now to **Mount device**.

7.1.7 Testing a Storage Device

- Press in the **information window** the **green function key (Benchmark)**, in order to check the storage device speed (see help text).


Benchmark
This test evaluates the quality for recording and playback with a test-file.
You need 0.5GB of free space to run the test, it might last several minutes.
Continue
Cancel

You can get the window for formatting your storage device, as well as for mounting and unmounting and for checking it also via the menu Media.

7.1.8 Personal Planner

Personal Planner is the Zappix HD+ timer menu. You can program recordings, channel selections or reminders.

- Select the submenu **Personal Planner** and press **OK**.
  or
  press **INFO** and three times the key ▶
  or

Press the key **USB** of the remote control. Following window opens:



- Press **OK**, in order that this window becomes an input window.
- Press the **green function key**, in order to add an event.
  - Navigate with the keys ◀ and ▶ to the start time, to the start date, to the end time, to the end date, to the channel and to the event settings.

This is the procedure to set start time and end time:

After you selected the time, the four digits begin to flash.

1. Press **OK**, in order to set the hours.
2. Press the keys ▲ and ▼, in order to change to the right hour value.
3. Press the key ▶, in order to set the minutes.
4. Press the keys ▲ and ▼, in order to change to the right minute value.
5. Press the key ▶, in order to go to the next input field (date).

This is the procedure to set start date and end date:

1. Press **OK**, in order to set the day.
2. Press the keys ▲ and ▼, in order to change to the right date.
3. Press the key ▶, in order to set the month.
4. Press the keys ▲ and ▼, in order to change to the right month.
5. Press the key ▶, in order to go to the next input field.

This is the procedure to set the channel:

1. Press **OK**, in order to change to set the channel.
2. Press the keys ▲ and ▼, in order to change to the right channel.
3. Press the key ▶, in order to go to the next input field.

Do not press **OK** during the procedures above!

This is the procedure to set the event type:

1. Press **OK**, in order to change to the setting of the event type. You'll get following window:

- Select with the keys ▶ and ◀ the button **Record**, in order to set the recording of the selected program. Press **OK** to confirm.
- Select with the keys ▶ and ◀ the button **Tune**, in order to switch to the selected program when it starts. Press **OK** to confirm.
- Select with the keys ▶ and ◀ the button **Reminder**, in order to display a notice (during the running program) when the selected program begins. Press **OK** to confirm.
- Press the key ▼, in order to change to the item **To take place**, where you can set the repeat mode.

For better comprehensibility we only will explain the settings regarding this item for the event type Record.

- Select with the keys ▶ and ◀ the button **Single**, in order to record the desired program one time.
- Select **Daily**, in order to record the selected program every day at the same time. Press **OK** to confirm.
- Select **Mon-Fri**, in order to record the selected program from Monday to Friday at the same time. Press **OK** to confirm.

- Select **Weekly**, in order to record the selected program every week always at the same day. Press **OK** to confirm.

2. Press the key ▼, in order to go to the button Confirm and press **OK**, in order to go back to the wind Full Guide.

7.1.9 List Manager

In this submenu you can delete the existing favorite lists, add new lists, rename existing lists and edit all channel lists (including your favorites list).

- Select in the menu **TV/Radio** the submenu **List Manager** and press **OK**
  or
  in TV mode press the key **INFO** and four times the key ▶, in order to go to the menu **Channel lists**.
  You'll get a window with the existing channel lists and three buttons at the bottom.



- Press **OK** once more, in order to change to the input mode. The first channel list (*Gesamt TV*) will be marked.

7.1.9.1 Delete a Channel List

- Select with the keys ▲ and ▼ one of the shown lists and press the **red function key**, in order to delete the list completely.

You cannot delete the channel lists, which have been created during channel search (e. g. the HD+ channel list Deutschland TV)!

7.1.9.2 New Channel List

- Press the **green function key**, in order to build a new channel list.

7.1.9.3 Rename Channel List

- Select with the keys ▲ and ▼ one of the shown lists and press the **yellow function key**, in order to rename the list (e. g. a new list with the default name *List1, List2,* …):
  - Press the **red function key**, in order to delete a character.
  - Press the keys **0 … 9** of the remote control, in order to insert letters, numbers and special characters.

Special characters are available via multiple pressing of the keys 0 (., !, ?, &, @) and 1 (all others).

  - Wait one second after each character, in order to confirm the input.
  - Press **OK**, in order to confirm the new name, to leave the edit mode, and to go back to the previous window.

7.1.9.4 Editing Channel Lists

- Select with the keys ▲ and ▼ one of the shown channel lists and press **OK**, in order to edit them additionally.

After **OK** you'll get the List Editor including two active areas:


Help message
Quick editing: use the 'left/right' arrows to toggle edition, and use 'Ok' to add or remove channels. From left side, 'Ok' adds channels to right list, while from right side, 'Ok' removes channels from the list.
List editor
Fri 10 May, 15:03
Gesamt TV
1 Das Erste HD
2 ZDF HD
3 BR Nord HD
4 RTL HD
5 Sat 1 HD
6 Vox HD
7 Prosieben HD
8 arte HD
9 Servus TV HD Deutschland
10 Kabel 1 HD
My Fav
Delete channel
Mark channel
Sorting
More options

- Switch with the keys ◀ and ▶ to those side (channel list / favorite list), on which you want to change something.
- Mark with the keys ▲ and ▼ the channel you want to edit.

7.1.9.5 Adding a Channel to a Favorite List

- Press **OK** on the left side of the **List Editor**, in order to add the selected channel to the favorite list.

7.1.9.6 Deleting a Channel from a Favorite List

- Press **OK** on the right side of the **List Editor**, in order to delete the selected channel from the favorite list.

> ☞ The order of the channels in a favorite list depends on the order of copying the channels from the channel list (is independent from the channels' positions in the channel list).

Furthermore, in the **List Editor** you have these possibilities (on both sides):

- Press the **red function key**, in order to delete the selected channel.
- Press the **green function key**, in order to mark the first of several channels. Enlarge the marking with the keys ▲ and ▼ and press once more the **green function key**, in order to set the end of the marking.

Now, you can add the marked channels to a favorite list or delete them from a favorite list.

7.1.9.7 Sorting a Channel List

➢ Press the **yellow function key** in the **List Editor**, in order to open the sorting function described in section 7.6, page 86.

7.1.9.8 Moving a Channel in a Channel List

1. Press on one side of the List Editor the **green function key**, in order to mark a channel.
   ➢ Enlarge the marking with the keys ▲ and ▼, if you want to mark several channels (sequent).
2. Press the green function key once more, in order to set the end of the marking (independently whether you marked one program or several programs).
3. Press the keys ▲ and ▼, in order to select the new position of the marked channel / the marked channels in the channel list.
4. Press **OK**, in order to move the marked channel / channels.

7.1.9.9 More List Editor Functions

1. Mark a channel.
2. Press the **blue function key** in the List Editor. The window **More options** opens.

➢ Select with the keys ▲, ▼, ◀ and ▶ the desired function and press **OK** in each case.

➢ Select **Edit from list**, in order to set the list on the left side of the **List Editor**.

➢ Select **Edit to list**, in order to set the list on the right side of the **List Editor**.

➢ Select **Lock/unlock channel**, in order to lock the access to the marked program or to unlock it.

You can only lock a program, if you selected *before Lock Settings + Channels* for the item **Set Access Rights Level** in the submenu **Parental Control**.

➢ Select **Show tech info**, in order to open the window **Technical Info** (see section 7.7, page 87).

7.2 Guide

The submenus **Today, Tomorrow,** … in the menu **Guide** offer for every day direct accses to the EPG.

➢ Select with the keys ◀ and ▶ one of the seven weekdays and press **OK**. The window **Full Guide** (for each day) opens (see paragraph 5.8.15, page 44).

7.3 Media Player

Via the menu **Media** you can play own TV recordings as well as audio, video and image files (photos), which are stored on a connected USB storage device or on a shared network folder in your home network[14]. How to share a folder or a drive in a Windows network is described in section 7.3.3 on page 65.

The Zappix HD+ can play this formats:

Audio	Video	Photo
• MP3	• AVI • MKV • MP4	• JPG • GIF • PCX

The list of supported formats may be extended by software updates.

➢ Ensure that a storage device containing the files you want to play is plugged in.

➢ Navigate to the menu **Media**.

[14] Only possible with the **smartPORTAL-Stick PX1**, which is available in the accessory shop on
www.smart-electronic.de

The submenu **Network** is only available after proper selection in the menu **Control panel/Network/Network files**.
With connected USB storage device you have an additional submenu **USB Flash Disk**.

- After selecting the submenu **All** and subsequent **OK** all the files on the connected storage devices (which can be only one) and all files on shared network folders will be displayed.
- After selecting the submenu **USB Flash Disk** and subsequent **OK** all files on the connected USB storage device will be displayed.

➢ In TV mode press **STOP** to show all files on the connected USB storage device.

- After selecting the submenu **Network**[15] and subsequent **OK** all files on shared network folders will be displayed.

➢ Select one of the submenus **All**, **Movies**, **Music**, **Photos** or **Home video** according to the type of the file you want to play and press **OK**. The folder tree now only shows the files that correspond to the desired file type.

Only if you have selected, for example music, you will see existing music files.

[15] only with connected **smartPORTAL-Stick PX1**

7.3.1 Network streaming

There are two basic requirements to be met for network streaming, i. e. the playback of files on a shared network folder:

7.3.1.1 Password

Assign a password to the user who is logged on the computer where the file to play back is located. To identify the computer in the network this is mandatory.

7.3.1.2 Firewall

For smooth streaming process, you must also ensure that the receiver is not blocked by a firewall. To prevent this, but keep the firewall activated, you need the IP address of the receiver (as seen via **Menu / Control panel / Network / Status** after the receiver has connected to the network) entering under *allowed addresses* (or similar).

7.3.2 Receiver Settings for Streaming

1. Connect the receiver to a home network (as described in section 4.6 “Connecting a Home Network (optional) “.
2. Go to Control panel / Network and press OK.
3. Ensure that **Network service** is *On*. Change the value if necessary.
4. Go to **Network files** and press **OK**. The window **Network files** opens.
5. Select **Network files** and press **OK**. Select the value *An* with the keys ▲ und ▼. Press once more **OK**, to go back to the window **Network files**.
6. Select **Auto-reconnection** and press **OK**. Select the values *An* or *Aus* with the keys ▲ und ▼, depending on whether you want the receiver connecting to your home network automatically after booting. Press once more **OK**, to go back to the window **Network files**.
7. Select **Network login** und and press **OK**. Insert the name of the computer containing the file to be played back with the numeric keys of the remote control, the sliderX[16]-keyboard or a connected USB keyboard. The input format should be:
   *Workgroup **or** Domain/Computername*

[16] sliderX = 4 in 1 universal remote control which is available as an accessory for the smart receivers CX10, VX10 and Zappix HD+.

Example.:
The file to be played back is located in a shared folder of the computer with the IP address 192.168.178.30 in the workgroup „Company1“. Insert Company1/192.168.178.30 under **Network login** and press **OK** to go back to the window **Network files**.

8. If your share requires a password, select **Network password** and press **OK**. Now use the numeric keys of the remote control, the sliderX keyboard or an external USB keyboard to enter the login password of the computer that hosts the file to play. If no password is required, this field remains empty. Press **OK** to return to the window **Network files**.
9. Press the green function key twice to confirm your entries and return to the Settings menu.
10. Turn off the receiver using the power switch on the back. Turn on the receiver again.
11. Now, under **Media / Network** you see the computer that hosts the shared file or folder.
12. Press **OK** to see the shared file or folder.

7.3.3 How to Share Folders and Drives

Here we describe the folder sharing in a windows home network while using a computer with Windows 7 Professional or Windows XP Professional. If you are working with a different operating system (Mac OS, Linux) or a NAS[17] drive, please refer to the respective manual for the right procedure.

For other Windows operating systems, the sharing of folders is similar, but often there is no possibility of detailed security settings!

7.3.3.1 How to Share Folders and Drives with Windows XP

Share Settings

1. Right-click the folder that you want to share, and then click *Properties*.
2. Select the *Sharing tab*.

[17] NAS = Network Attached Storage, storage device (hard disk) which is directly connected to the network

3. Click the Share This Folder option.
4. Type the *Share Name*.
5. Click Permissions.
6. Set for the group *Everyone* the desired permissions and confirm all menus. If you only want to stream, i. e. playback via the receiver, in most cases only *read permissions* are necessary. If the group *Everyone* does not exist, click on *Add…*, type *Everyone* in the object names box, click on *Check names* and confirm all inputs.

File System Permissions

Additionally you must set the proper permissions directly in the file system:

1. Right-click the file or folder you want to share.
2. Click Properties.
3. Select the *Security* tab.
4. Check whether in the names box the group *Everyone* is existing. If the group *Everyone* does not exist, click on *Add…*, type *Everyone* in the object names box, click on *Check names* and confirm all inputs.
5. Set for the group *Everyone* the desired permissions and confirm all menus. If you only want to stream, i. e. playback via the receiver, in most cases only *read permissions* are necessary.

7.3.3.2 How to Share Folders and Drives with Windows 7

With the introduction of **Windows 7**, Microsoft has changed the security concept. Sharing of any folder / drive is very complex, if you are using a device that does not support Windows 7 (for example a PC with an earlier version of Windows or a Linux PC, the smart receiver). To share a folder a number of steps are necessary:

Share Settings

1. Right-click the folder that you want to share, and then click *Properties*.
2. Select the *Sharing tab*.
3. Click the button *Advanced Sharing*.
4. Click the Share This Folder option.
5. Type the *Share Name*.

6. Click Permissions.
7. Check whether in the names box the group *Everyone* is existing. If the group *Everyone* does not exist, click on *Add…*, type *Everyone* in the object names box, click on *Check names* and confirm all inputs.
8. Set for the group *Everyone* the desired permissions and confirm all menus. If you only want to stream, i. e. playback via the receiver, in most cases only *read permissions* are necessary.

File System Permissions

Additionally you must set the proper permissions directly in the file system:

1. Right-click the file or folder you want to share.
2. Click Properties.
3. Select the *Security* tab.
4. Click *Edit*.
5. Click *Add*.
6. Type *Everyone* in the textbox and confirm the menu.
7. Set for the group *Everyone* the desired permissions and confirm all menus. If you only want to stream, i. e. playback via the receiver, in most cases only *read permissions* are necessary.

Disable Password Protection

You need to ensure that the access is allowed from other PC with one user name and one password.

1. Open the Control Panel.
2. Click *Home group*; (if you are in category view it's directly on the first page, if you are in symbol view open *Network and Sharing Center*).
3. Click Advanced Sharing Settings.
4. Open the active profile (probably *home* or *work)*.
5. Scroll until you see password protected sharing.
6. Switch off *password protected sharing* and confirm all.

If you can adjust security settings for the user group *Everyone*, your home network does not include several workgroups or domains and your sharing is not password protected, you can insert what you want for **Network login– but the Field must not be empty!**

7.3.4 Example Music

- Select with the keys ▲ and ▼ the file you want to play (you open a directory with **OK**).

If you are already in a subdirectory, you go to the parent directory by selecting the icon "**. .**".

- Press **OK**, in order to start playback (or press the key ⏯).
- Use the keys ⏪, ⏩, ⏯ and ⏹ to control the playback.

In order to go quickly to a certain point in an audio or video file, use the keys ⏮ and ⏭ (13). Keep the key pressed until the desired position is reached. Do you release the key, the device conducts synchronization and playback starts.

- Via the buttons at the bottom of the media player window further options are available.
- Select with the keys ▲ and ▼ a music file and press the **red function key**, in order to delete the file. Following window opens:



  - Select with the keys ◀ and ▶ **Yes** or **No** and confirm with **OK**.
    If you select **Yes** the file will be deleted and you get back to the previous window.
    If you select **No** only the current window will be closed.

- Select with the keys ▲ and ▼ a music file and press the **yellow function key**, in order to enter the edit mode, in which you can rename the file:
  - Press the **red function key**, in order to delete a character.
  - Press the keys **0 … 9** of the remote control, in order to insert letters, numbers and special characters.
  - Wait one second after each character, in order to confirm the input.
  - Press **OK**, in order to confirm the new name, to leave the edit mode and to go back to the previous window.

Do not change the file suffix (e. g. .mp3), in order to ensure that the file is recognized as music file and played back properly.

- Press the **blue function key**, in order to define an opened directory as standard directory for recording or time shift (see section 7.1.3, page 52).

7.3.5 Example Photos

The basic procedure for image files is similar to those for music files.

- Press **OK**, after you selected an image file, in order to show a preview of the image.
- Press **OK once more**, in order to show the image in full screen format.
- Press ⏯, in order to start a slide show of all images in the selected directory.

7.4 Web

The speed of displaying content from the Internet depends on many factors, e. g.

- The internet access speed,
- the number of current users on a dial-in node
- the transmitted data volume via this dial-in node .

With plugged in **smartPORTAL-Stick PX1** and properly configured WLAN connection you have via the menu **Web** access to the **smart portal** and

thus to a variety of Web services such as weather forecast, audiobooks, music, video portals, magazines, over 300 web radio stations and much more.



Press the **yellow function key** in order to directly access the **smartPORTAL** from TV mode.

The smart web offerings are continuously enhanced. For details, visit www.smart-electronic.de.

7.5 Control Panel

In the menu **Control Panel** you can adjust many parameters in several sub-menus for the operation of the Zappix HD+ and view the current settings.

1. Navigate to the menu **Control Panel**.
2. Press **OK**.

Basically, the procedure is always the same:

3. Open a submenu with **OK**. A two-part window is displayed: the left side contains several menu items with the currently set value; the right side of the window is empty.
4. Select with the keys ▲ and ▼ a menu item and confirm with **OK**. On the right side now all selectable values are shown.
5. Select with the keys ▲ and ▼ a value and press **OK**, in order to take this value. Now you have the possibility to edit other menu items in the same submenu with the keys ▲ and ▼.
6. Press the **green function key**, in order to confirm the changes and to go back to the menu **Control Panel**.
   Press the **red function key**, in order to go back to the menu **Control Panel** discarding the changes.

7.5.1 User Preferences

7.5.1.1 Default State of the Receiver After Power-Up

- Select **Start-up mode** to define, whether your Zappix HD+ starts up with the live-TV screen or whether there is already the menu opened („Lobby“).

7.5.1.2 Number of Channels in the Channel Memory

- Select **“Last“ history depth**, in order to set how many channels are stored in the channel memory. Whenever you see a channel a few seconds, this is then stored in memory. Use the **RECALL** key to call easily after maximum five switching operations one of these channels.

7.5.1.3 Setting the Energy mode

- Select **Energy mode**, in order to set the energy mode being used in standby mode:

Energy mode	Meaning
Economic	Minimum power consumption, longer start-up time
Light standby	Middle power consumption, middle start-up time
Rapid start-up	Higher power consumption, very short start-up time

7.5.1.4 User Interface

- Select **User interface** and press **OK** to set the appearance of the menu windows.

7.5.1.4.1 Background Image

- Select **Interface color scheme** to set the background image of the OSD. You can select between *Default* and *Skin1*.

7.5.1.4.2 OSD Transparency

- Select **OSD transparency** to set the transparency of the info window and the quick access menus. You can select between these values: *100% (opaque), 90%* and *80%.* Default value is *100%.*

7.5.1.4.3 Pop-Up Menus Duration

- Select **Pop-up menus duration**, in order to set the time, how long the **info window** (see section 5.8.5, page 34) and other info text is displayed. You can select the values *3s, 6s* und *9s.* Default value is *3s.*

7.5.1.4.4 EPG Font Size

- Select **EPG font size**, in order to set the font size in the **Full Guide** window (section 5.8.15, page 44). Default value is *small*.

7.5.1.4.5 Menu Font Size

- Select **GUI font size**, in order to set the font size in the menu windows. Default value is *small*.

7.5.1.5 Quick View Window Behavior

- Select **Quick Tuning**, in order to set, whether in the **Quick view** window (see section 5.8.1, page 32) the channel should switch with the selection of a channel (*On*) or whether you must press **OK** to switch (*Off*).

7.5.1.6 Getting Informed About Existing HbbTV Content

- Select **HbbTV Applications**, in order to set, how you want to be informed about existing HbbTV content or how you want to use it[18]. There are these options:

[18] Only applicable with plugged in smartPORTAL-Stick PX1 and properly configured WLAN connection.

Value	Description
Disabled	HbbTV contents (or just the availability of HbbTV contents) are **not** displayed.
Auto-start	Immediately after channel switch you'll get the „HbbTV-indication"-button (e. g. for most German channels it is „Einblenden"), the keys for Navigation and the function keys are assigned to the HbbTV content (the receiver operation may be restricted).
Notify	In the info window you'll get an icon (), if the selected channel contains HbbTV content.
Auto-Red	Similar to *Auto-start*; until you open the HbbTV application the keys for Navigation and the function keys except the red function key are reserved for the receiver operation.

7.5.1.7 Automatic Standby-Mode

➢ Select **Auto Standby**, in order to set, whether the receiver should automatically switch to standby mode, when there isn't any key pressed for a certain time.

7.5.1.8 Functions for the Keys FAV, EPG and HELP

There are default functions for the keys **FAV** and **EPG**. Nevertheless you can assign other functions.

7.5.1.8.1 Function of the Key FAV

➢ Select **key 'FAV'**, in order to set the function for the key **FAV**:

Value	Meaning
FAV	**Choose default list** (section 5.8.2, page 33), default function
Planner	**Personal planner** (section 7.1.8, page 55)
Library	Open the menu **Media / USB** … (section 7.3, page 62)

7.5.1.8.2 Function of the Key EPG

➢ Select **key ,GUIDE/EPG**, in order to set the function for the key **EPG**:

Value	Meaning
TV guide	Open the EPG (section 5.8.15, page 44), default function
single channel guide	Open the **Quick view** (section 5.8.1, page 32)

7.5.1.8.3 Function of the Key HELP

With plugged in **smartPORTAL-Stick PX1** and properly configured WLAN connection you can also assign another function to the key **HELP**:

- Select **key 'HELP'**, in order to set the function for the key **HELP**:

Value	Meaning
HELP	Opens the smart support website, default function
Web	Opens the smart portal (section 7.4, page 69)

7.5.1.9 Automatic Playback of a Multimedia File

- Select **Auto playback** to set,
  whether the playback of a multimedia file (audio, video, photo) starts only by selecting the file (*On*)
  or
  whether you must press ► or **OK** to start the playback (*Off*)
  or
  whether playback starts with 3 seconds delay after selecting the file (*3 sec*). When playing a TV recording, you already see captured EPG data during these 3 seconds.

7.5.1.10 Leaving the Menu "User preferences"

If you leave during the change process the submenu **User preferences** with **EXIT**, a query appears:

- Select with the keys ◄ and ► your answer and confirm with **OK**.

- *Yes:* The changes you did already were saved and you go back to the menu **Control Panel**.
- *No:* The changes you did already were discarded and you go back to the menu **Control Panel**.
- *Cancel*: No action, you stay in the submenu **User preferences**.

7.5.2 Time / Date

➢ Select **Automatic time update**, in order to set whether the receiver takes over the system time of the satellite signal (*On*), or whether you want to enter the time manually (*Off*).

Select *On* if you want to use HD + programs in future!

➢ Select **Date**, in order to enter the current date:

The menu item **Date** is only active, when you selected **Automatic time update** *Off*!

1. Select with the key ▶ day, month and year and change with the keys ▲ and ▼ to the right values.
2. Press **OK**, in order to complete the date entry.

➢ Select **Local time**, in order to insert the current time:

The menu item **Local time** is only active, when you selected **Automatic time update** *Off*!

1. Select with the key ▶ hours and minutes and change with the keys ▲ and ▼ to the right values
2. Press **OK**, in order to complete the time entry.

➢ Select **Time zone**, in order to set the time zone, where you are (where you operate the receiver). For Germany e. g. the right value is *Amsterdam GMT+1*.

➢ Select **Auto-daylight saving time** (*On* / *Off*), in order to set whether the system time should automatically adjusted according the daylight saving time (daylight saving time from the last Sunday in March until the last Sunday in October)

- Select **Daylight saving time**, in order to adjust the system time according the Daylight saving time manually.

The menu item **Daylight saving time** is only active, when you selected **Auto-daylight saving time** *Off*!

7.5.3 Languages

- Select **Menu Language**, in order to set the OSD language.
- Select **Primary sound track language**, in order to set the default language for programs with multi-channel sound.

The Zappix HD+ default value is *Deutsch*.

- Select **Primary subtitle language**, in order to set the language of broadcasted subtitles.

Whether the selected language is really played, depends on whether the current program with multi-channel sound contains this language.

The same applies analogously to **Primary subtitle language**.

7.5.4 Recording

7.5.4.1 Setting Lead Time and Overrun Time

- Select **Start guard buffer**, in order to set with the keys ▶ and ◀ the minutes a recording should start earlier than set in the **Personal Planner**.
- Select **End guard buffer**, in order to set with the keys ▶ and ◀ the minutes a recording should stop later than set in the **Personal Planner**.

7.5.4.2 Setting Default Directories for Recordings and Timeshift

- Select **Default Record Folder** to get advice in which menu you can set the default directory for recordings.
- Select **Default Timeshift Folder** to get advice in which menu you can set the default directory for timeshift.

7.5.4.3 Channel Change During Recording

- Select **Independent Watch & Record** to set, whether the receiver always shows the program that is been recorded or not:
  On Channel change is possible (default)
  Off Channel change is not possible.

7.5.4.4 Recording Subtitles

- Select **Record with Subtitles** to set, whether you want to record subtitles (which are then also available during playback).

7.5.4.5 Recording Audio Tracks

- Select **Record with Audio Tracks** to set, whether you want to record all broadcasted audio tracks (which are then also available during playback).

7.5.4.6 Recording Teletext

- Select **Record with Teletext** to set, whether you want to record broadcasted teletext data (which are then also available during playback).

7.5.4.7 Power at the USB Port

You can set, whether a connected USB hard drive (without own power supply) should be in operation during standby.

- Select **USB Power in Standby**, to switch on or off the 5V voltage at the USB port during standby.

If you selected *Off* and a Timer which is programmed for recording starts the receiver, there is one minute lead time in order to save enough time to initialize (“boot up”) the HDD.

7.5.4.8 Blocking the menu during recording

- Select **Recording Protection**, to set, whether the menu can be callled during recording.

On the menu cannot be called during recording.

Attention!

Calling of certain menu items and functions, can lead to dropouts in the recording or to a termination.

7.5.5 Parental Control / Pin Code

➢ Select **Change Pin Code**, in order to set the PIN[19]. The PIN allows you to restrict the access to channels and menus.

The default value for the Pin code is *0000*.

➢ Select **Restrict content rating**, in order to restrict the access to channels with limited FSK-approval[20].

Example: If you set the value to *12 years old*, during the further operation channels will be blocked, broadcasting currently programs with a higher FSK approval (16, 18).

The function **Restrict content rating** can only be used, when this service is provided by the provider, i. e. programs must contain a flag for the FSK approval.

➢ Select **Set Access Rights Level**, in order to restrict the access to channels or menus with the PIN.

7.5.6 Network

If there is a plugged in **smartPORTAL-Stick PX1** (available separately) you can configure in this menu the access to a wireless home network and thus to the Internet.

7.5.6.1 Wireless Network – WLAN

➢ Press **Wireless network**, in order to configure a wireless network connection (WLAN, only VX10).

[19] PIN = **P**ersonal **I**dentification **N**umber, secret numeric password
[20] FSK = Freiwillige Selbstkontrolle der Filmwirtschaft (German) = Voluntary Self Regulation of the Movie Industry, FSK approval: e. g. rating of a film according to the youth protection law

➢ If you operate your Zappix HD+ the first time you have to select **Manually connect to a wireless network** (**Automatic Search for wireless networks** is not selectable).

7.5.6.1.1 Automatic WLAN Configuration

➢ Select **Automatic search for wireless networks**. After **OK** the receiver looks for the wireless network you gave during first install and establishes the connection.

7.5.6.1.2 Manual WLAN Configuration

➢ Select **Manually connect to a wireless network**. After **OK** the receiver looks for the wireless network looks for the available wireless networks.

1. Select your network and press **OK**. Beside the network connection you should insert your key / password.
2. Insert your WLAN key with the numeric keys of the remote control and press **OK**, in order to confirm your entry.
3. Press the **green function key (Connect)**. The receiver connects with the network. At the top of the screen it is indicated if the connection is established successfully.

7.5.6.1.3 Connecting to a hidden wireless network

1. Select **Connect to a hidden wireless network**. The window **Connect to a hidden wireless network** opens.
2. Select **SSID**[21], press **OK**, and enter the network name.
3. Select **Security** to set the encryption method.
   You can select between *None, WEP, WPA, WPA2*.
4. Press the **red function key (Exit)** or **BACK**, in order to go back to the previous window. Press **EXIT**, in order to leave the menu.

7.5.6.1.4 WLAN: fixed IP Address or DHCP

➢ Select **Auto IP config** to set,
whether you the receiver shoul have a fixed IP address in the wireless network (*No*)

[21] **S**ecure **S**et **I**dentifier (engl.) = Netzwerkkennung

or
whether the IP address should be given via **DHCP** (*DHCP*).

7.5.6.2 Showing Network Connection Parameters

➢ Select **Status,** in order to open the **Status** window (see above).

7.5.6.3 Activating a Network Quality Control

➢ Select **Network service**, in order to activate a network quality control.

7.5.7 Channel Search

7.5.7.1 Satellite Search

In the submenu **Satellite Search** you can create overall channel lists (TV and Radio) for one or for several satellites.

➢ Select **Scan mode**, in order to set the way of creating a new overall channel list:
Quick Scan: searches all channels which are available from a satellite.
HD+: the HD+ channel list will be used.

➢ Select **Channels**, in order to set, whether only FTA[22] or all channels should be searched.

➢ Select **Satellite**, in order to set, which satellites should be included in the search.

Which satellites are selectable here, is set in the sub-menu Antenna (see section 7.5.12, page 84).

➢ Press the **green function key (Start Search)**, in order to start the channel search.

7.5.7.2 Advanced Channel Search

In the submenu **Advanced Channel Search** you can search for channels of a certain transponder.

➢ Select **Satellite**, in order to select the satellite, where the transponder is located.

[22] FTA = **F**ree **T**o **A**ir = unscrambled channel

Which satellites are selectable here, is set in the submenu Antenna (see section 7.5.12, page 84).

- Select **Frequency**, in order to set the transponder frequency.
- Select **Polarity**, in order to set the polarization of the desired channel.
- Select **Symbol Rate**, in order to set the symbol rate of the desired channel.
- Select **DVB-S2**, in order to set, whether you look for a HD channel (DVB-S2) or a SD channel (DVB-S).
- Select **FEC**, in order to set the FEC mode.

If you set the FEC mode (i. e. do not leave it *Automatic*), the search will be simpler and the search time will be shorter.

- Select **PIDs**, in order to set the PID values. If you do not know them, set the value to *Automatic*. Then the PIDs provided by the broadcaster will be used.
- Only if you select *manual*, you can insert values for **Video PID**, **Audio PID** and **PCR PID** with the numeric keys of the remote control
- Select **Channels**, in order to set, whether only FTA or all channels should be searched.

7.5.8 Factory Settings

The access to the submenu **Factory Settings** is always protected by the PIN (independently from the settings in **Parental Control**).

- Select **Factory Defaults**, in order to reset the receiver (to set the delivery status).
- Select **Preprogrammed Channel Lists**, in order to set *Standardliste* or *Blankoliste* as default channel list (see section 5.3.1, page 25).
- Select **Export settings to USB**, in order to save settings and channel lists to a USB storage device.
- Select **Import settings from USB**, in order to load settings and channel lists from an external a USB storage device.

7.5.9 System Update

➢ Select the submenu **System Update**, in order to update the receiver software online (see section 5.4, page 27).

➢ Please, ensure that the receiver is connected to the internet, if you want to update the receiver software online.[23]

7.5.10 System information

Here you can get several information regarding your Zappix HD+.

Especially if you want to contact the smart service hotline, you should know the receiver's software version.

7.5.11 Audio / Video

7.5.11.1 Digital Audio Out

➢ Select **Digital Audio Out**, in order to switch the digital audio out between *Stereo (downmix)* and *Dolby*[24] *bitstream*.

Value	Meaning
Stereo (downmix)	The multichannel audio signal is reduced to two channels.
Dolby bitstream	The audio signal is available in multichannel format to be transferred to a multichannel amplifier.

If a DTS signal is transmitted, this is available at the SPDIF output (Digital Audio Out must be set to *Dolby bitstream*).

7.5.11.2 HDMI Output

➢ Select **HDMI Output**, in order to switch the HDMI output signal between *RGB*, *YPbPr 4:4:4* and *YPbPr 4:2:2*.

[23] Only possible with the **smartPORTAL-Stick PX1**.
[24] Meant is the multi-channel audio system Dolby Digital (also known as AC3)

➢ Please, follow the instructions of your TV manual for proper adjustment.

7.5.11.3 TV Scart

➢ Select **TV Scart**, in order to switch the Scart output signal between *RGB and* FBAS.

7.5.11.4 HDCP

➢ Select **HDCP**, in order to select, whether the HDMI signal should be transferred with a HDMI security code.

If you turn off HDCP (for example, because your TV set cannot handle HDCP signals), certain playback functions may be blocked.

7.5.11.5 Disable Analog Video Output

➢ Select **Analogue video output** to select,
whether you want to deactivate the analog video outputs completely (*Off*) **or**
whether only the pure video signal (without OSD information windows) should be available. Press the key **16:9**, in order to undo the deactivation.

The deactivation of the analog outputs (Scart), you can increase the quality of the Internet presentation.

When recording with an external video recorder you can avoid distracting video overlays by selecting the menu option *Video*.

7.5.11.6 Adaptive Scan HDMI

➢ Select **Adaptive Scan HDMI** to select whether the refresh rate on the HDMI output should be adjusted to the refresh rate of the film material (24Hz, 25Hz, 50Hz, 59.94 Hz, 60 Hz). However, this can lead to an image loss of 2-5 seconds each time you start playback. The adjustment is suitable when playing NTSC recordings (59.94 or 60 Hz) and movies (24 Hz), for which a frequency of 50 Hz is not optimal.

You can choose between *Off, 50/60 Hz* und *24/50/60 Hz*
Off: no adjustment

50/60 Hz: adjustment between 50 and 60 Hz (Europa / USA)
24/50/60 Hz: adjustment between 24, 50 and 60 Hz.

7.5.12 Antenna

The settings made by smart (factory-settings) are valid for a standard satellite system. Any additional system features (like multi-feed LNB, unicable system ...) need to manual adjustments in the submenu **Antenna**:

➢ Leave the settings in this menu to a professional.
For normal use, you do not have to make any settings here.

With the help of the indication of signal quality and signal strength you can verify your entries immediately.

- ➢ Select **LNB Type**, in order to select *Universal* LNB or *Unicable* LNB.
- ➢ Select **Satellite**, in order to select the satellite, for which you want to change the settings.
  - ➢ Press the **green function key (Insert satellite)**, in order to increase the list of satellites.
- ➢ Select **LOF Low Band**, in order to define the LOF Low Band value (depends on the LNB).
- ➢ Select **LOF High Band**, in order to define the LOF High Band value (depends on the LNB).
- ➢ Select **Band Switching**, in order to set, whether the switch between Low Band and High Band should be done automatically.
- ➢ Select **DiSEqC type**, in order to set the used DiSEqC mode: *Mini DiSEqC*, *DiSEqC 1.0* or *DiSEqC 1.1*.
- ➢ Select **DiSEqC input**, in order to set, which DiSEqC input should be valid for a selected satellite. Depending on the DiSEqC mode you have these options:

DiSEqC mode	Inputs
None	*Not selectable*
Mini DiSEqC	*A, B*

DiSEqC mode	Inputs
DiSEqC 1.0	*A, B, C, D*
DiSEqC 1.1	*1, 2, 3, 4, 5, 6, 7*

➢ Select **Ref. Transponder**, in order to set the transponder, which should be used to evaluate signal quality and signal strength (i. e. the transponder, which provides your preferred channel)
or
Select **Frequency**, in order to insert with the numerical keys of the remote control the frequency of the reference transponder.

7.5.13 Smartcard

Since the Zappix HD+ is a HD+ receiver, a smartcard bay is available.

You can remove the smartcard at any time or insert it without turning off the receiver.

➢ Insert the smartcard **with the chip down** carefully until the contacts inside snap into place.

After the smartcard is inserted, the corresponding channel can be selected. It may take a few seconds, until the channel is unlocked.

In the **Zappix HD+** smartcard bay you can only insert HD+ smartcards!

When you first select a HD+ channel, the HD+ card is activated for 12 months! When these first 12 months are over, you have to extend the HD+ subscription with Astra HD+. With the extension of the subscription you give your HD+ card number; then an activation code is sent via satellite.

7.5.14 RAPS Config

➢ Select **RAPS Config**, in order to set,

a) Whether after reset to factory defaults the channel list will be created from scratch or whether it only will be updated and

b) Whether automatic updates will be performed.

The access to the submenu **RAPS Config** is always PIN-protected (independently from the settings in the submenu **Parental Control**).

7.6 Sorting Channels

1. Press the remote control key **EPG**.
2. Press die **yellow function key**, in order to open the window **Sorting** on top of the EPG window **Full Guide**.
   Dependent on your installation (with RAPS or without RAPS), you'll get different windows **Sorting**
   e. g. with RAPS:



In TV mode you can press the blue function key, in order to access directly the sorting function.

3. Press the keys ◀, ▶, ▲ and ▼ in order to select the desired sorting function and confirm with **OK**:
   - *Unsort*: the channel list is displayed unchanged.
   - *Sort A-Z*: all channels will be displayed in alphabetical order.
   - *Sort Satellite*: all channels will be displayed sort by the transmitting satellite.
   - *Sort Language*: all channels will be displayed sort by the broadcasted language.
   - *Sort. CAS*[25]: all channels will be displayed sort by the channel type FTA or „scrambled".
   - *HD filter*: only HD channels will be displayed.
   - *CAS filter*: the window **CAS filter** opens:
     Select with the keys ◀, ▶, ▲ and ▼ a kind of scrambling and confirm with **OK**.

[25] CAS = Conditional Access Sender = scrambled broadcasting

Now, only channels with this kind of scrambling and FTA channels will be displayed.

- *Genre filter:* the window Genre filter opens.
  Select with the keys ◀, ▶, ▲ and ▼ a Genre and confirm with **OK**.
  Now, only channels which belong to this Genre will be displayed.

4. Press **EXIT**, in order to leave the EPG window and to go back to normal TV operation.

7.7 EPG More options

1. Press the remote control key **EPG**.
2. Press die **blue function key**, in order to open the window **More Options** on top of the EPG window **Full Guide**:

3. Select with the keys ◀ and ▶ the desired function.
   - **Show tech info** opens this window:



No.	Item	Meaning
1	FTA	Free To Air (not scrambled)
2	ASTRA 1F,H,KR,L,M	Satellite name
3	Polarity: H	Polarization of the satellite signal H = horizontal, V = vertical

No.	Item	Meaning
4	Video PID: 3071	Each table or each elementary stream in a transport stream is determined by a 13 bit PID.
5	Genre: Documentation	Shows the kind of programs on the current channel
6	Symbol Rate: 27500	Symbol Rate in MHz
7	Audio PID: 3072	See "Video PID"
8	Current Language	Default language for programs with multi-channel sound
9	Frequency: 12460 MHz	Frequency in MHz
10	Service ID: 659	For each channel there is a unique number.
11	PCR PID: 3071	PCR = Program Clock Reference, built on the PIDs, necessary that the decoder works properly.

- **Edit scheduled event** opens the programming window of the **EPG**, where you can program recordings, channel selection or reminders (see section 6.2, page 48).

4. Press **EXIT**, in order to leave the **EPG** window and to go back to normal TV operation.

7.8 Using USB Input Devices (Mouse, Keyboard)

For your convenience you can operate a USB keyboard with the Zappix HD+.

For easy navigation on smartPORTAL pages (Internet), it may be helpful to have a mouse available.

In some cases (e. g. if alphanumerical entries are necessary), it can be reasonable to use, a complete keyboard, additionally with the remote control.

In the menus/submenus keys are available with these functions:

Key	Description
Numbers 0 ... 9	
Letters	
←→↑↓	Navigation in the menu or change of a value
RETURN key	**OK**

In the Internet application you can use these keys:

Key	Description
Numbers 0 ... 9	
Letters	
Shift key	Upper / lower case
Space bar	
Deletion key Del	
RETURN key	
TAB	Go to next field
Alt + TAB	Go to previous field
F3	Go to previous page
F4	Go to next page
F5	Refresh
F6	Display video in full screen mode
F7	Video pause
F8	Video play
SHIFT KEY + -	Slash (/)

Key	Description
CTRL ±	Magnification / reduction (software)
Num lock + CTRL ±	Magnification / reduction (hardware)

7.8.1 The USB Mouse or the USB Keyboard is the only USB Device

Example:

You want to use only live TV (no recordings) and therefore do not need a USB disk. You also use the Internet either with mouse **or** with keyboard.

- Connect a USB mouse or a USB keyboard to the receiver (USB interface at the rear). You can use the device now.

7.8.2 Several USB Devices

If you want to use the recording and / or time shift functions in conjunction with a USB storage device, or mouse and keyboard should be available simultaneously, you need to connect several USB devices.

1. Connect a USB hub to the USB socket on the back of the receiver
2. Connect a USB keyboard to the USB hub. You can use the keyboard now.
3. Connect to the USB hub one or several USB storage devices.

Instead of a USB mouse and USB keyboard, you can also use a wireless keyboard-mouse combination ("wireless desktop"). This has the advantage that only one USB slot is occupied.

The total power consumption of all connected USB devices may not exceed 500 mA.

8 Operation in a Unicable System

8.1 About Unicable

The HDTV receiver smart Zappix HD+ can be operated at a unicable system. Depending on the type of system it is possible to connect up to eight receivers to one trunk line.

In order to achieve that, at each receiver in the setup menu, a separate IF channel and a corresponding frequency must be set.

The allocation of channels and frequencies depends on the used LNBs or multiswitches.

The data sheet and the technical documentation for your LNB and / or multiswitch contain a mapping table similar to the following.

8.2 Allocation ZF Channels and Frequencies

Receiver	ZF channel	Example frequency (MHz)	Frequency (MHz)
Receiver 1	1	1210	
Receiver 2	2	1284	

Receiver	ZF channel	Example frequency (MHz)	Frequency (MHz)
Receiver 3	3	1400	
Receiver 4	4	1420	
Receiver 5	5	1516	
Receiver 6	6	1632	
Receiver 7	7	1748	
Receiver 8	8	1864	

➢ Fill in the last column of the table the frequencies of your system, thus you always have all the relevant information at a glance.
The rule of thumb is: maximum frequency → shortest cable path.

8.3 Installation

1. If the receiver is connected to a unicable system, start the installation as described in section 5.2, page 22.
2. Press the **blue function key** at the end of the countdown to the RAPS-install, in order to open the submenu Antenna.
3. Select the **LNB Type** *Unicable*.
4. Check whether the values for LOF Low Band and LOF High Band correspond to the used LNB (default values are 9750 and 10600). You may need to adjust the values.
5. Set the IF frequency (one of the selectable IF frequencies in ascending order for each connected receiver in the system.
6. Set the respective channel (one of the selectable channels in ascending order for each connected receiver in the system).
7. Exit the menu by pressing **EXIT** (the settings are stored).
8. Select the menu **Control Panel**, the submenu **Config RAPS** and enter the PIN code.

9. Make sure that the value for **RAPS Mode** is *Config*. You may need to change this value.
10. Press the **yellow function key** to start the RAPS installation.
11. Go on as described in section 5.2, page 22.

9 Management of USB Storage Devices

For recording, time shift and media player functions mainly USB storage devices (USB sticks, USB hard drives) are used. Therefore, their use is described below in detail.

9.1 USB Sticks

In general, USB sticks can be used. However, it must be ensured, that the read and write speed of the USB stick is higher than 12 MByte/s.

Too low read and write speed can cause problems during recording (stuttering, still images). The internal memory (buffer) is overloaded and the recording is stuttering for a moment. As soon as the data is processed in the internal memory, the recording will continue.

If the write speed of a connected storage device is not high enough for proper recording, a corresponding notification window opens.

9.2 USB Hard Drive 2.5 "(Inch)

2.5" USB hard drives are normally powered via the USB connector.

Check the power consumption of your hard drive (consult the hard drive user manual), since the smart receivers provide a maximum current of 500 - 600 mA.

If the power consumption of the drive is higher, it must be supplied with an external AC adapter.

If this is not possible, programmed recordings cannot be processed or they are defective.

9.3 USB Hard Drive 3.5 "(Inch)

3.5" USB hard drives have their own power supply.

Therefore, we recommend hard drives of this size for the operation along with smart receivers.

9.4 Check the Read and Write Speed

You can test the read and write speed of your USB storage device with various programs.

In the support section of the website www.smart-electronic.de you can find such a program to download.

The read and write speed of your storage device must be more than 12 MByte/s to ensure an error-free operation.

9.5 File System

The smart Zappix HD+ supports die file systems FAT16, FAT32 and Ext2.

With FAT32, the size of individual files is limited to 4GB. If a recording file size exceeds this, the file is automatically split into several parts.

9.6 Partitions on the Storage Device

The memory of a USB storage device can be split in several parts - so-called partitions.

Smart recommends to partition disks with a size of 500 GB, while the partitions should be no larger than 500 GB.

Examples:

- You do not need partition a disk with 400 GB.
- A 1000 GB hard disk should be divided into two partitions of 500 GB.

Use the second (or third) partition on the disk to archive recordings. Connect the external disk to your PC and move the recordings to the second partition.

So, you have always enough disk space on the first partition, and have the possibility to clean up the first partition from time to time.

9.7 Memory Requirements for Recording

- SD recordings need about 40 MB / minute (2.5 GB / hour).
- HD recordings need about 120 MB / minute (7.0 GB / hour).

9.8 Troubleshooting USB Storage Devices

Symptom	Possible reason	Corrective
Recording jerky, still image	Inadequate read and write speed of the disk: the internal memory (buffer) of the USB stick is overloaded. Storage device/ fie system damaged	Check read and write speed Windows error checking (see next section)
Recording stops prematurely	Disk full, No more space available.	Disk cleanup, Windows disk defragmentation
Disk does not start with the programmed timer	2.5 "hard drive with too high power consumption First partition on the disk exceeds 250GB	Check the power consumption of disk, possibly using a different storage device Repartition the disk; First partition with max. 250GB
Disk is not recognized	Disk is not compatible with the receiver, unsupported file system, inadequate read and write speed Cable connection broken	Matching and tested storage devices can be found at the smart accessories store (at www.smart-electronic.de) Check USB cable
Hard drive keeps running, even though receiver is in standby	Hard drive does not support standby function	Check technical data of the hard disk

9.9 Error Checking in Windows

In the following we describe the procedure for the operating system Windows XP. If you have a different operating system, find out a possibly different procedure in the manual of your PC or operating system.

1. Connect the disk to the PC.
2. Open **My Computer** and click on the disk with the right mouse button.
3. Select Properties.
4. Go to the **Tools** tab.
5. Under Error Checking click the button **Check Now**. The window **disk check** opens.
6. Select both options (file system errors and bad sectors).
7. Start error checking and correction by clicking on **Start**.

10 Cleaning

WARNING!

Risk of electric shock!

- Pull the mains plug from the mains socket before cleaning.
- Never clean the receiver with a moist cloth.
- Liquids must be prevented from entering the unit.

CAUTION!

Risk of damage!

- Do not use any solvent-containing cleaners such as benzin or thinner.
- Clean the housing of the receiver with a dry cloth.

11 Transport and Shutdown

This is the procedure, if you want to transport the receiver or do not want to use it anymore:

1. Disconnect the receiver and the connected units from the power supply.

2. Pull all connected cables.
3. Remove the batteries from the remote control.
4. Place the receiver, cables and remote control in the original packaging.
5. Store the receiver and all accessories at a dry and dust-free location.
6. Protect the receiver from frost.

12 Troubleshooting

This section contains a list of common errors that can occur during operation of the receiver. For each error a possible cause and the recommended correction are given.

Symptom	Possible cause	Corrective Action
Display is not illuminated.	The power cable has not been connected. The main switch has not been switched on.	Connect the power cable to the mains socket. Switch on the mains switch.
No sound or picture, in the receiver display the current time is shown.	Receiver is in standby mode.	Press the power key, in order to switch on the receiver.
No sound or picture.	No signal or only a weak signal.	Check the cable connections to the receiver and from the receiver to the connected units and fasten them, if necessary.
The TV set has no picture.	The system is not connected properly. The TV set is not in the AV mode.	Check the connection of the scart or composite cable and fasten it. If necessary switch the TV set to the appropriate AV input.
Picture only black and white and/or not properly synchronized.	The video format of your receiver is not set properly.	Adjust the TV standard of your receiver to that of the TV set.

Symptom	Possible cause	Corrective Action
The remote control is not working.	The batteries are used up. The remote control is aligned incorrectly.	Replace the batteries with new ones. Direct the remote control at the front panel of the receiver.
The display is flashing.	Short circuit at the antenna input.	Unplug the antenna connector at the LNB input and check it. Make sure that your antenna system is installed properly.

If necessary, new operating software will be published for the receiver. It can easily be downloaded via satellite or from the website www.smart-electronic.de.

If a malfunction cannot be eliminated by new software or the above measures, please contact your specialized dealer.

Service Hotline

If you have problems with the procedures, with the connections or with general settings:

Service-Hotline: +49 (0) 7724 947 85 55

Fax: +49 (0) 7724 947 83 33

E-mail: service@smart-electronic.de

Internet: www.smart-electronic.de

13 Disposal

CAUTION!

- Never throw receiver and batteries in the normal domestic waste!

- Inquire at your city or local government about proper and environmentally suitable disposal methods for the unit.
- Take used-up batteries to a collection point.

The WEEE[26] symbol on the product or its packaging indicates that this product is an electric or electronic unit. Do not dispose of this unit with the domestic waste, but take it your local communal collection point (recycling center).

14 Specifications

14.1 General

- HD+ compliant
- FULL HD 1080p
- Standby Save Energy Mode
- 6000 channels
- 8 favorite lists
- EPG
- Enhanced playback: MP3, AVI, MKV, MP4, JPG, GIF, PCX

Input frequency	950 MHz ~ 2150 MHz
Input impedance	75 Ω
Input level	-65 dBm to -25 dBm
LNB current	13/18 V, max. 400 mA
LNB control signal	0 / 22 kHz
DiSEqC control	full DiSEqC support

[26] WEEE = Waste Electrical and Electronic Equipment. The WEEE directive is the EC directive 2002/96/EC on reduction of the increasing amount of waste from electrical and electronic equipment not used any more. Its objective is prevention, reduction and environmentally friendly disposal of the increasing amounts of electronic waste.

14.2 Remote Control	
Range	Up to 7 m
Batteries	2 size AAA
14.3 LAN/WLAN	
LAN	10/100Mbit/s
TCP/IP	IPv4 (IPv6 is not supported!)
WLAN (with smartPORTAL-Stick PX1 only)	802.11b/g
- Speed	54Mbit/s
- Encryption	WEP, WPA and WPA2
14.4 Power Supply	
Power consumption in deep-standby mode	Less than 0.5 W
Voltage	175 - 250 V ~, 50/60 Hz
14.5 Connections	
Storage device interface	USB 2.0
Tuner input (LNB IN)	IEC 169-24
Tuner loop through (LNB OUT)	IEC 169-24
Audio output	1 cinch socket - digital audio (SPDIF)
	1 opt. socket - digital audio (SPDIF)
	2 cinch sockets
Video output	1 HDMI socket
	1 scart socket (EURO AV)
	1 chinch socket - composite video (FBAS)
14.6 Temperature	
Operating temperature	0° C to +40° C

Storage temperature	-40° C to +65° C

14.7 Dimensions and Weight

Width	260 mm
Height	50 mm
Depth	215 mm
Weight	Approx. 1,5 kg

15 Open-Source-Software

The smart Zappix HD+ software contains different modules of an open source operating system, which are available according to the

- GNU GENERAL PUBLIC LICENSE, Version 2 and the
- GNU LESSER GENERAL LICENCE, Version 2.1

Both licenses have been defined and published by the FSF (Free Software Foundation).

These in Zappix HD+ used parts of the software source code can be provided free of charge upon request.

Below you'll find the complete terms of the

- GNU GENERAL PUBLIC LICENSE (GPL) and der
- GNU LESSER GENERAL LICENCE (LPGL)

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA

Everyone is permitted to copy and distribute verbatim copies

of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may

be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any

such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.
one line to give the program's name and an idea of what it does.
Copyright (C) *yyyy name of author*

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) *year name of author*
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

signature of Ty Coon, 1 April 1989
Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies

of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts

as the successor of the GNU Library Public License, version 2, hence

the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of

Section 1 above, provided that you also meet all of these conditions:

a) The modified work must itself be a software library.

b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.

c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.

d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary

form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.
one line to give the library's name and an idea of what it does.

Copyright (C) *year name of author*

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:
Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

signature of Ty Coon, 1 April 1990
Ty Coon, President of Vice

That's all there is to it!

16 Declaration of Conformity

The smart electronic GmbH, Industriestrasse 29, 78112 St. Georgen, Germany declares that this product complies with the following guidelines and standards:

- **EMC Directive 2004/108/EC**
  - EN 55013: 2001 + A1: 2003 + A2: 2006
  - EN 55020: 2007
  - EN 55022: 2006 + A1: 2007
  - EN 55024: 1998 + A1: 2001 + A2: 2003
  - EN 61000-3-2:2006
  - EN 61000-3-3:2008
- **Low Voltage Directive (LVD) 2006/95/EC**
  - EN 60065: 2002 + A1: 2006 + A11: 2008

Doc-ID: 12121302